

Instruction Manual

ULTRASONIC FLOWMETER

TYPE: PUX2 (Flow transmitter) PSX2 (Detectors)



This manual explains cautions in use, wiring, operation, installation, troubleshooting and maintenance, and options of the portable type ultrasonic flowmeter Please read through the manual thoroughly before using the instrument.

Keep this manual available for reference by appropriate operation and maintenance personnel.

Manufacturer: Dwyer Instruments, Inc.Type: Described in nameplate on main frameDate of manufacture: Described in nameplate on main frameProduct nationality: Japan

Note) Windows, Windows NT, Windows Vista, Excel, are registered trade marks of Microsoft Corporation. Modbus is a registered trademark of Schneider Automation.

Notice

© Dwyer Instruments, Inc. 2008

Issued in August, 2008

- This manual and contents may not be copied or reused in whole or in part without prior permission.
- Contents of the manual are subject to change without prior notice.

Bulletin F-9-PUX2

1. (OVERVIEW	. 1
2.	CHECK OF DELIVERED ITEMS	. 2
2.1	On purchase of flow transmitter (type: PUX2)	2
2.2	On purchase of detector (type: PSX2)	
2.3	Reserved for future use	4
3.	CHECK MODEL AND SPECIFICATION	. 5
4.]	NAME AND EXPLANATION OF EACH PART	. 8
4.1	Name and explanation of main unit and detector	8
4.2	Explanation of keys	10
4.3	Handling of SD memory card	11
	4.3.1 Precautions for handling of SD memory card	
	4.3.2 Formatting forms	
	4.3.3 Insertion and removal	
	4.3.4 Data recording to SD memory card	.13
5.]	POWER ON AND POWER OFF	16
5.1	Operating power supply	16
5.2	Turning on the power and language preference	.17
5.3	Power OFF	18
6.	WIRING	19
6.1	Diagram	19
6.2	Connection of dedicated cables	19
6.3	Connection of analog input/output cable(4 to 20 mA DC)	.20
6.4	Connection of USB cable	20
7.]	NPUT OF PIPING SPECIFICATIONS	21
7.1	Display of pipe setup screen	21
7.2	Entry of site name (not required measurement)	.24
7.3	Outer diameter of piping (unit: mm)(range: 13 to 6000 mm)	.27
7.4	Piping material	.28
7.5	Wall thickness (unit: mm) (range: 0.1 to 100.00mm)	.29
7.6	Lining material	30
7.7	Lining thickness (unit: mm) (range: 0.01 to 100.00 mm)	31
7.8	Kind of fluid	
7.9	Viscosity	
7.1	C	
	1 Kind of sensor	
	2 Transmission voltage (used when an indicator is 1 or less during measurement)	
7.1	3 Completion of PROCESS SETTING	.37
8. 1	MOUNTING OF DETECTOR	38
8.1	Selection of mounting location	.38
8.2	Selection of detector	41

8.3	Use of surface-treated accessories	43
8.4	How to mount small size (standard) sensor and small outer diameter sensor to pipe	44
8	8.4.1 How to mount a sensor (V method)	
8	8.4.2 How to mount a small size (standard) sensor (Z method)	45
8.5	How to mount large and medium size sensor	47
	8.5.1 How to determine mounting position	
8	8.5.2 How to connect medium size sensor	48
8	8.5.3 How to connect large size sensor	50
8	8.5.4 Mounting of medium type sensor on pipe	51
8	8.5.5 How to mount large size sensor to pipe	53
8.6	How to mount high temperature sensor to pipe	54
	6.1 How to mount a sensor (V method)	
8	8.6.2 How to mount a sensor (Z method)	55
8.7	How to fold gage paper (used for determining mounting position)	57
9. S	TART MEASURING	58
	ETTING OPERATION (APPLICATION)	
	How to use SITE SETUP function (SITE SETUP page)	
	0.1.1 SITE MEMORY: when registering data which are set and calibrated on the page	
	0.1.2 ZERO ADJUSTMENT: when performing zero adjustment	
	0.1.3 UNIT OF OUTPUT: when changing unit of each output	
	0.1.4 OUTPUT CONTROL: when controlling measured value (output control function)	
	0.1.5 TOTALIZER: when performing the total process of measured data (totalize)	
	Setting of data logger function	
	0.2.1 "Logger Operation" mode	
	0.2.2 Logger data file format	
	0.2.3 LOGGING: when logging (recording) measured data	
	0.2.4 "LOGGER DATA": when checking or printing logged data	
	Setting of system (SYSTEM SETUP screen)	
	0.3.1 BASIC SETUP: when setting the system	
	0.3.2 "ANALOG INPUT/OUTPUT": when performing analog input/output and calibration	
	0.3.3 "CALORIE MODE": when measuring consumed heat quantity	
	Setting of range (setting screen for input/output range)	106
1	0.4.1 Setting the input range: When setting the range for the input current or input voltage.	
	Setting range: 0.000 to ±999999999	
	0.4.2 Setting the output range	
	Use of printer function (PRINTER screen)	
	0.5.1 Selection of printing mode	
	0.5.2 Example of printing	
	0.5.3 PRINT OF TEXT	
	0.5.4 PRINTING OF GRAPH	
	0.5.5 PRINT OF LIST	
	0.5.6 STATUS DISPLAY	
	Maintenance function (MAINTENANCE screen)	
	0.6.1 Checking receiving status for transit time	
1	0.6.2 Check for analog input/output	122

10.6.3 SD memory card	
10.6.4 LCD check	127
10.6.5 Software	
10.7 Flow velocity distribution display function (optional)	130
10.7.1 Installing Detector	
10.7.2 Operation	
10.8 Contents of errors in status display	
10.8.1 How to check status display	
10.8.2 Action on error	141
11. MAINTENANCE AND CHECKUP	
12. ERROR AND REMEDY	146
12.1 Error in LCD Display	146
12.2 Error of key	146
12.3 Error in measured value	147
12.4 Error in analog output	150
13. EXTERNAL COMMUNICATION SPECIFICATION	151
14. HOW TO USE PRINTER	
14.1 How to connect printer	152
14.2 How to load printer roll sheet	154
15. REPLACEMENT OF BUILT-IN BATTERY	155
16. APPENDIX	156
16.1 Piping data	
16.2 Command tree	164
16.3 Specifications	166
16.4 Q & A	171
16.5 File contents of SD memory card	
16.5.1 Types of measured data to be logged	
16.5.2 Measured data file	
16.5.2 Measured data file16.5.3 Flow velocity profile data file	177

WARNING SYMBOLS AND THEIR MEANINGS

Be sure to observe the following precautions. They offer important information on safety.

• The degree of injuries or damages resulting from improper handling of this device is indicated by different symbols.




Improper handling of this device may cause dangerous situations that result in personal injury or property damage.

• The following symbols describe items to be observed.

\bigcirc	The symbol indicates "prohibition".	Do not modify this device.
0	The symbol indicates "mandatory" action to be taken.	Be sure to pull out the plug.
	The symbol provokes "cautions".	Be careful. It may result in fire.

Bulletin F-9-PUX2 SAFETY PRECAUTIONS

Be sure to read the "Safety Precautions" carefully beforehand for the correct and safe use of this device.





Keep warning labels clean.



Clean or replace the warning labels so that they can always be read correctly. Otherwise it may result in an accident.

Ask an authorized waste disposal specialist for disposal.



Do not dispose the device without proper authorization. Otherwise it may cause environmental pollution or result in an accident.

Do not splash water.



Do not wash or splash water on the electrical parts inside the device.

Otherwise it may result in electric shock.

Be careful when carrying the device.



When carrying the device, exercise care to avoid physical shock or vibration. Otherwise it may cause failure.

For connecting the cable, turn the power off.



For connecting cable to terminal of the middle size detector (Type: PSX2-E), or the large size detector (Type: PSX2-D), turn the power off.

Inspect the power plug periodically.



Inspect the power plug once every 6 months. Wipe the dust off the plug and insert it securely. Otherwise it may result in electric shock or fire.

Match power capacity with the device ratings.



Be sure to connect the device to the power source of proper voltage and current rating. Otherwise it may result in fire.

Use an exclusive power adapter and built-in battery.



Do not use a power adapter or built-in Lithium ion battery that is not exclusive to the main unit. Otherwise it may break and cause failure.

Prohibition

 Ambient temperature: Charge time; 0 to +40°C In use; -20 to +60°C Storage time; -20 to +50°C

Use the device in favorable environment.



Do not use the device in an environment subjected to dust or corrosive gases. Otherwise it may cause failure.

Flow transmitter

- Ambient temperature:
- -10 to +55°C (Without printer)
- -10 to +45°C (Witt printer)
- Ambient humidity: 90% RH or less

Detector:

- Ambient temperature: -20 to +60°C
- · Ambient humidity:
- Large/middle size detector; 100% RH or less Others; 90% RH or less

Cause of machine malfunction.



Use in a place which is remote from electrical devices (motor, transformer, etc.) which generate electromagnetic induction noise, electrostatic noise, etc.

Cause of machine malfunction.



Do not use in a place which is near cell phones, wireless devices, etc., which may cause the machine blunder.

Prohibition

Fire or damage may result.



Except the main unit (printer, power adapters, etc.), it is not protected for dust or waterproof. Avoid using the product in a place

where it will be exposed to water or humidity.

1. OVERVIEW

This PUX2 is a portable type ultrasonic flowmeter that allows easy measurement of flow rates in pipes by installing a set of sensors on the outside of the piping.

A combination of the latest electronics and digital signal processing technologies enables the instrument to provide a compact and convenient solution to accurately measure system flow rates without breaking or opening the serial transmission and removable memory card functionality allows easy data acquisition and analysis.

2.1 On purchase of flow transmitter (type: PUX2)

Conversion unit	Without printer (PUX2)	Carrying case	
	With printer (PUX2-PR)	Strap	
AC power supply adapter Power connector conversion cord		Dedicated signal cable (5m×2 pcs) BNC adapter	Ó
Power cord		CD-ROM Instruction manual Loader Instruction manual	
Analog input/ output cord (1.5m)		Roll paper	
USB cable (1m)		SD memory card (256MB)	Арасст Соберение и соб Соберение и соберение и соберен

On purchase of detector (type: PSX2) 2.2 The following parts are included. (1) Main unit (Type: PSX2-D) (Type: PSX2-A) (Type: PSX2-B) (Type: PSX2-E) (Type: PSX2-HT) (2) Accessories Kind of PSX2-PSX2-PSX2-PSX2-PSX2-Quantity Remarks detector D Е А В HT • Fastening springs ()2 pcs • \$\$ 2mm wire rope ()2 pcs Plastic cloth belt ()()()1 pc • Stainless steel belt 4 pcs (long) \bigcirc 2 pcs (short) • Silicone grease Mfg: Shinetsu Chemical Industry () ()()()1 pc Shin Etsu Type: G40M (100g) • Grease for Mfg: Shinetsu high temperature Chemical Industry 1 pc \bigcirc Type: KS62M (100g) • Cable for exclusive use (BNC at both ends) 2 pcs \bigcirc \bigcirc \bigcirc \bigcirc • Cable for exclusive use (BNC at one end) 2 pcs \bigcirc

2.3 Reserved for future use

3. CHECK MODEL AND SPECIFICATION

The specification plates attached to the frame of flow transmitter and the detector list the type and specifications of the product.

Check that they represent the type ordered.



Check Part number on identification plate.

Check part identification & specification (cont'd)

Note)


Use a guide rail for applications in which ultrasonic signal penetration is difficult, for example piping is very old, cast iron pipe, piping with mortar liners, or high turbidity liquid or flow profile.

Applicable diameter Range:


V Method: 50mm to 250mm (1.97 in. to 9.84 in.) (PSX2-HT)

V Method: 50mm to 300mm (1.97 in. to 11.81 in.) (PSX2-A)

Z Method: 150mm to 400mm (5.91 in. to 15.75 in.)(PSX2-HT, PSX2-A)




Check part identification & specification (cont'd)



Location of identification plates

PSX2-C

4.1 Name and explanation of main unit and detector



 Keyboard 	: Used for turning on/off power supply of the main unit, controlling the
	printer, inputting fluid specifications and setting the transmitter functions.
• Display window	: Displays measured value. Also used for display during programming and
	data input.
	Because this is a large-size graphic LCD, indications are easy to read.
	Even at a dark place, indications can be read by using the backlight.
• Printer (option)	: Capable of printing all information of the transmitter including print of
	display screen capture and printout of measured value.
	*Transmitter includes a logger function (for storing measured values in
	memory). After storing a few day's data in memory by the logger function,
	it may be printed.
	Note) Chinese language selection will print Japanese.
• Detector	: Attached to a pipe and receives/transmits ultrasonic waves.
• Cable for exclus	ive use:
	Used for transmitting and receiving signals between transmitter and detec-
	tors for flow measurement.
• Rubber	: Protects the main unit from drop impact etc.



• Connectors : 12V DC

Connector of main unit power supply. Inputs 12V DC.

Insert the plug of the power adapter specified for this instrument.

- : UP STREAM (upstream side), DOWN STREAM (downstream side) Receptacles to connect detector cables.
- Connect matching the upstream and downstream sides.
- : ANALOG IN/OUT
 - Connect analog input/output signals (4 to 20mA DC).
- Analog input signal: 2 points
 - CH1: 4 to 20mA DC or 1 to 5V DC
 - CH2: 4 to 20mA DC
- Analog output signal: 1 point
 - 4 to 20mA DC

: USB

- USB port. Connect to an external system such as personal computer.
- : SD memory card
- SD card slot. The measurement data and the screen data can be saved.
- : Contrast adjusting knob

Adjust the LCD contrast.

Note) Be careful not to lose the protective cap attached to power connector and analog input/ output connector.

4.2 Explanation of keys

Fig. 3-1 shows the layout of keys and Table 3-1 explains each key.



Fig. 4-1 Layout of keys

Key indication or lamp	Description
ENT	The keyed-in data, selected item, etc. will be set by pressing this key.
ESC	Cancels any setting.
	Moves the cursor upward, increments set value, etc. (repeats if held down)
▼	Moves the cursor downward, decrements set value, etc. (repeats if held down)
•	Moves the cursor leftward, change scale, etc. (repeats if held down)
•	Moves the cursor rightward, change scale, etc. (repeats if held down)
ON/OFF	Turns on/off power supply.
PRINT	Print of the display screen or save the data to SD memory card. (outputs a hard copy).
्रें (LIGHT)	Turns on/off the backlight of display screen.
FAST CHARGE	Turns ON in charge. Turns OFF in fully charged condition.
DC IN	Turns ON with power cable connected.
MENU	Displays MENU screen.

4.3 Handling of SD memory card

Use an SD memory card for recording measured data, flow velocity profile data and screen data. The equipment is capable of accommodating an SD memory card of capacity up to 8GB. An SD memory card of capacity 256MB is provided as an option. Compatible media

- SD memory card
 - Speed class: Class2, 4, 6
- SDHC memory card Speed class: Class4, 6

4.3.1 Precautions for handling of SD memory card

- (1) Use an SD memory card or SDHC memory card that has been formatted based on a standard.
- (2) Make sure to format the SD memory card or SDHC memory card based on its standard.
- (3) Firmly insert the SD memory card (or SDHC memory card; hereinafter the same) in the appropriate direction, and assure that it has been properly mounted.
- (4) Do not remove the card during data read/write operation. Data may be broken or erased. It is recommended that data stored on the card is periodically backed up. Important data is lost if the SD memory card is broken. Make sure to back up the data on the SD memory card.

4.3.2 Formatting forms

For formatting an SD memory card, use dedicated formatting software the memory card manufacturer provides. Data read/write is not permitted if the card is not property formatted.

- Formatting forms
 - FAT12: 64MB
 - FAT16: 128MB, 256MB, 512MB, 1GB, 2GB
 - FAT32: 4GB, 8GB

4.3.3 Insertion and removal

Methods for insertion and removal of an SD memory card are described below.

- (1) Insertion
 - Step 1) Open the cap from the main unit bottom face.



SD memory card slot

Step 2) Insert a memory card into the memory card slot in the main unit bottom face in the direction shown on the right.Card push-in system is adopted for card mounting. Positively push in the memory card to the lock-up position.



When inserting, align the memory card body to match the slot.

Do not insert the card at an angle. Card should slide into slot freely without force. If the memory card is pushed with force in the state where the card is inserted as tilted, the connector in the main unit will be broken. Be careful.

(2) Removal

Card push-in system is adopted for card mounting. Push the card in straight. The card is unlocked and can be removed.

The data stored on a memory card can be directly read with a PC.



- Do not remove the memory card during data write operation.
- Do not remove the memory card before the main unit identifies the inserted memory card after its insertion.
- Be careful with static electricity at the time of removal of the memory card.

4.3.4 Data recording to SD memory card

(1) Types of recorded data

Recorded data is of three different types indicated below.

(1) Measured data: One logger file is composed of a configuration file and a data file.

Configuration file: Records logger start-up time and relevant logger data files.

Data file: Records logging data in a specific period produced by logger and quick logger.

The data file is stored as divided by 65,500 lines for permitting high-speed access and due to restrictions in the maximum number of lines of CSV display of spreadsheet software.

- (2) Flow velocity profile: Records flow velocity plofile data for an hour.
- (3) Screen copy: Records screen display copy data.

(2) File configuration

Recorded data is stored as files on an SD memory card.

The file configuration is such that a folder of site name is located just beneath the root folder and the following data manipulated by the subject site name is stored beneath said folder.

A folder of site name is created at the time of registration of a site name described in "10.1.1 SITE MEMORY".

The recorded data is stored in the folder of the site name selected by site selection described in "10.1.1 SITE MEMORY".

(1) Measured data ... Just beneath the folder of site name

Case of logger

- Configuration data file name of created logger: logging name_date_hour.ini
- Data file name of created logger: logging name_date_hour.csv

Case of logger

- Configuration data file name of created logger: QUICK_date_hour.ini
- Data file name of created logger: QUICK_date_hour.csv

A data file can be edited with spreadsheet software.

See "16.5.2 Measured data file" located toward the end of the volume for the recording format.

(2) Flow velocity distribution ... Beneath VEL folder just beneath folder of site name

• Created flow velocity distribution data file name: Vel date hour.csv

A data file can be displayed using flow velocity distribution demonstrate function of PC loader software.

See "16.5.3 Flow velocity distribution file" located toward the end of the volume for the recording format.

(3) Screen copy ... Beneath DISP folder just beneath folder of site name

• Created screen copy file name: DISP_date_hour.csv Recording format: bitmap




Fig. 4-2 File configuration

(3) Recording capacity

The recording capacity depends on the capacity of the SD memory card. One logger file is composed of a configuration file and a data file. The data file is stored as divided by 65,500 lines for permitting high-speed access and due to restrictions in the maximum number of lines of CSV display of spreadsheet software. The maximum number of data files in a logger is 20 files in case of a continuous logger, and is 550 files in case of an appointed time logger. If the capacity becomes short during logging operation, logging operation terminates with the following screen displayed. Replace the SD memory card immediately, if this screen is displayed. Press the screen dependence of the memory card, the message will be cleared.

Note) After reaching the maximum data file, the logging will stop.



Recording capacity in case an SD memory card of 256 MB is used with continuous logger Where the preservation period is 30 seconds and where logger data of all of 14 types is stored, it is possible to store measured data for about a year.

In the case stated above, the measured data is divided into 16 files, and the capacity of a file is about 15 MB.

See "10.2.1 Setting of data logger function" for the continuous logger and appointed time logger. See "16.5.1 Types of measured data to be logged" for logger data types.

5.1 Operating power supply

There are two methods available for energizing this instrument; by the built-in battery or with the power adapter.

(1) Energizing with built-in battery

(1) To charge the battery

Turn OFF the instrument power and connect the AC power adapter. The "CHARGE" LED is lighted in red, and "DC IN" LED is lighted in green. When the instrument is fully charged, "CHARGE" LED goes out.



* About 3 hours will be required for charging..

* In the fully charged condition, the instrument can measure for about 12 hours. (On condition that the display backlight is turned off and the printer is unused, do not use current output. The ambient temperature is near normal temperature (20°C).)

- Note) The charging limit of the built-in battery is 0 to +40°C. If the charging is operated beyond that range, it will cause hi-temp leak, performance deterioration, and short battery life.
- (2) To energize by built-in battery

When turning on the power supply without connecting the power adapter, the instrument will be energized by the built-in battery.

Before use, the battery should be fully charged.

(2) Energizing by power adapter

- Use the exclusive power adapter only. Don't use other adapters, or it may result in an accident.
- Except the main unit (printer, power adapters, etc.), it is not protected for dust or waterproof.

Avoid using the product in a place where it will be exposed to water or humidity.

• AC power adapter

- Connect the power connector conversion mode to the output plug for AC power adaptor. (The products have already been connected.)
- (2) Connect the plug of the power connector conversion mode to the 12V DC connector of the main unit. Inserts joining the connected projection to the cutout, turns the sleeve lock.
- (3) Insert the input plug of this adapter into the power receptacle. This adapter has an input voltage range of 90 to 264V AC (at 50/60Hz).
- (4) Insert the input plug of AC adapter into the outlet.




5.2 Turning on the power and language preference

(1) Press the ON switch of the main unit to turn ON the power.



- (2) Turn ON the power, and the following screen appears.
- (3) If no selection is chosen on the the screen for about 5 sec. the "MEASURE" screen appears.




- Note1) Select any of 6 languages (Japanese, English, German, French, Spanish, and Chinese).
- Note2) To return to the "Language Selection" screen from the "MEASUREMENT" screen in display, turn OFF the power once and then turn it ON again. In the initial screen that is displayed, press the (ENT) key.

5.3 Power OFF

(1) Power OFF by [OFF] switch

Keep pressing the [OFF] switch on the main unit for 3 seconds or longer, to turn OFF the power.

In case where measured data is being logged to an SD memory card, execute logging interrupt processing before turning OFF the power.




(2) Power OFF caused by drop in capacity of built-in battery

In case of operation with built-in battery, the power is turned OFF about 40 minutes (see Note) after remaining capacity short (___) is indicated.

In case where measured data is being logged to an SD memory card, execute logging interrupt processing before turning OFF the power.

Note) This length of time varies by ambient temperature and battery conditions. The time depends on use conditions.



NORMAL

(3) Precautions for parameter setup change

When parameter setup is changed, parameters are stored in the internal non-volatile memory upon return to the measurement screen.


The stored parameters are held even when the power is turned OFF.

Caution: If the power is turned OFF without returning to the measurement screen after parameter setup changes, the parameters are not stored, and setup is required again.

Do not operate the main unit using an AC power adaptor in the state where the builtin battery is removed from the main unit.

• If the power cable is disconnected from the power outlet or if power failure arises while measured data is being logged to the SD memory card, the data written to the SD memory card may be lost.

6.1 Diagram




To connect PC

6.2 Connection of dedicated cables


This cable is used for connecting the detector to the main unit.

- (1) Connect dedicated cables to the upstream and downstream sides of the detector.
- (2) Connect one cable connected to the upstream side of the detector to the "UP STREAM" connector of the main unit, and connect the other cable connected to the down stream side of the detector to the "DOWN STREAM" connector.




6.3 Connection of analog input/output cable (4 to 20 mA DC)

This cable is used for connection of receiving instruments (indicators, recorders, etc.) and flow transmitter to the main unit. Analog I/O cable is connected as shown below. The cable end is treated with a clip.




- (1) Connect clips of the analog I/O cable to the (+) and (-) sides of the receiving instruments, respectively.
- (2) Connect the analog I/O cable to the "AI/AO" connector at the side panel of the main unit. Note) Allowable load resistance of analog output should be adjusted to 600Ω or less. Input resistance of analog input is 200Ω .



6.4 Connection of USB cable

When PC software is used, open the cap of down face of the main unit and USB port of PC; transmit connecting "USB" port with USB cable. For PC software, refer to Chapter 12.




7. INPUT OF PIPING SPECIFICATIONS


Before installing the detector, set the specifications of a pipe in the main unit to allow measurements. Caution) Measurements cannot be accomplished without these settings.


7.1 Display of pipe setup screen

- (1) Press the MENU key on the "MEASURE" screen to display the "MENU" screen.
- (2) Check that the "SITE SETUP" is reversed from white to blue.




(3) Press the ENT key, and the "SITE SETUP" screen is displayed.








(5) Pressing the *ENT* key returns to the "PROCESS SETTING" screen.



(6) Outline of PIPE PARAMETER (Parameter \rightarrow Page No. for reference)




(7) Display of mounting dimensions


After you finish the site setting on establish site screen, "Decision" is reversed from white to blue by pressing (ENT) key.

Displays the message "After mounting the sensor, perform Zero point adjustment", then goes back to "SITE SETUP" screen.

At the last line the "SENSOR SPACING" value is displayed.



Install the sensor according to chapter 8. MOUNTING OF DETECTOR and the mounting dimension is as displayed on the last line.




mately ± 2 to 5%.


7.2 Entry of site name (not required measurement)

Enter the name of the site (where measurement is performed). This name is registered with process setting ((4) of page 21).


- (1) Move the cursor to "1: SITE MEMORY" on the SITE SETUP screen.
 - Note) Before setting the "2. Establish setting", the Site registration is required.
- (2) Press the (ENT) key to display the SITE MEMORY screen.
- (3) Press the ENT key after checking that cursor is placed in the MODE.

(4) When the mode selection screen appears, move the cursor to "REGISTRATION" and press the (ENT) key.









(7) Move the cursor to "END" and press the ENT key to complete the character entry.

A	17	N.										
м	1 (4	_	_	_	_	_	_	_	_	_	_
A	В	С	D	Е	F	G	Н	1	J	К	L	M
Ν	0	Ρ	Q	R	S	Т	U	۷	W	Х	Y	Ζ
а	b	С	d	е	f	g	h	i	j	k	1	m
n	0	р	q	r	s	t	u	V	W	Х	У	Ζ
1	2	3	4	5	6	7	8	9	0	Q	_	
R	3	C	٩N	ſ	-NI)						

When moving the cursor in the character entry field	
Press the (ESC) key so that the cursor " " will change to " \blacksquare ".	REGISTRATION
	A1C
	ABCDEFGHIJKLM NOPQRSTUVWXYZ abcdefghijklm nopqrstuvwxyz 1234567890@_ BS CAN END
The cursor can be moved by the \bigcirc and the \bigcirc key.	REGISTRATION
	A 🗋 C
	ABCDEFGHIJKLM NOPQRSTUVWXYZ abcdefghijklm nopqrstuvwxyz 1234567890@_ BS CAN END
For entering characters to the place the cursor is moved, press the (ESC) key	REGISTRATION
The cursor moves to the character entry field.	A 1 C
	A B D E F G H I J K L M N O P Q R S T U V W X Y Z a b c d e f g h i j k l m n o p q r s t u v w x y z 1 2 3 4 5 6 7 8 9 0 0 _ BS CAN END

Note 1) Entry can be made with alphanumeric characters.

Note 2) To stop character entry in the middle, select "CAN" and press the *ENT* key. The original SITE MEMORY screen reappears.

7.3 Outer diameter of piping (Range: 13 to 6000 mm / 0.51 to 236 inch)


The "OUTER DIAMETER" is reversed from white to blue, on the "PROCESS SETTING" screen


Press the (ENT) key, the screen of "OUTER DIAM-ETER" for selecting the input method of outer diameter measurement and "PERIMETER" screen will appear.


Press the (ENT) key after the selection to enter the outer dimension.

Use the \bigcirc or \bigcirc key to cause the digit to move in the right and left direction Use the \bigcirc or \bigcirc key to enter the numeric value. After entry, press the (ENT) key.


Note) Enter outer dimensions, not nominal diameter (example: $20A \rightarrow 20$).








(ENT



7.4 Piping material

Press the \bigcirc key so the "PIPE MATERIAL" is reversed from white to blue. Press the \bigcirc key, and the "PIPE MATERIAL" screen will appear.

Select the material by the a or V key. After entry, press the ENT key.





Example) When	the pip	oing material is cas	st iron:
PROCESS SETTING PIPE MATERIAL CARBON STEEL STAINLESS STEEL PVC COPPER CAST IRON		PROCESS SETTING PIPE MATERIAL CARBON STEEL STAINLESS STEEL PVC COPPER CAST IRON	ENT

7.5 Wall thickness (range: 0.1 to 100.00mm / 0.004 to 3.9 in.)


Press the \bigcirc key, so the "WALL THICKNESS" is reversed from white to blue. Press the ENT key, Wall thickness can be entered (See pages 156 to 162, Piping Data). Use the \bigcirc or \bigcirc key to move the digit to the left and right.

Using the \bigcirc or \bigcirc key, enter the value. After entry, press the (ENT) key.











7.6 Lining material

Press the \checkmark key, so the "LINING MATERIAL" is reversed from white to blue. Press the ENT key, the "LINING MATERIAL" screen will appear.

Select the material, using the \bigcirc or \bigcirc key. After selection, press the ENT key.



₹ 2/4 ► ENT PROCESS SETTING LINING MATERIAL NO LINING TAR EPOXY MORTAR RUBBER TEFLON PYREX GLASS PVC OTHERS	ENT PROCESS SETTING LINING MATERIAL NO LINING TAR EPOXY MORTAR RUBBER TEFLON PYREX GLASS PVC OTHERS	ENT PROCESS SETTING LINING MATERIAL NO LINING TAR EPOXY MORTAR RUBBER TEFLON PYREX GLASS PVC OTHERS	PROCESS SETTING PROCESS SETTING LINING MATERIAL NO LINING TAR EPOXY MORTAR RUBBER TEFLON PYREX GLASS PVC OTHERS	LINING M LINING S LINING T DECISIC	NO V.	LINING 🗸 O m/s O.OO mm
PROCESS SETTING LINING MATERIAL NO LINING TAR EPOXY MORTAR RUBBER TEFLON PYREX GLASS PVC OTHERS	PROCESS SETTING	PROCESS SETTING	PROCESS SETTING LINING MATERIAL NO LINING TAR EPOXY MORTAR RUBBER TEFLON PYREX GLASS PVC OTHERS	4	2/4	₽
LINING MATERIAL NO LINING TAR EPOXY MORTAR RUBBER TEFLON PYREX GLASS PVC OTHERS	LINING MATERIAL NO LINING TAR EPOXY MORTAR RUBBER TEFLON PYREX GLASS PVC OTHERS	LINING MATERIAL NO LINING TAR EPOXY MORTAR RUBBER TEFLON PYREX GLASS PVC OTHERS	LINING MATERIAL NO LINING TAR EPOXY MORTAR RUBBER TEFLON PYREX GLASS PVC OTHERS		ENT	
NO LINING TAR EPOXY MORTAR RUBBER TEFLON PYREX GLASS PVC OTHERS	NO LINING TAR EPOXY MORTAR RUBBER TEFLON PYREX GLASS PVC OTHERS	NO LINING TAR EPOXY MORTAR RUBBER TEFLON PYREX GLASS PVC OTHERS	NO LINING TAR EPOXY MORTAR RUBBER TEFLON PYREX GLASS PVC OTHERS	PROCESS	SETTING	
				NO LI TAR E MORTA RUBBE TEFLOI PYREX PVC	NTNG POXY R R GLASS S	




7.7 Lining thickness (unit: mm) (range: 0.01 to 100.00 mm)

When the lining material is set to items other than "None" in 7.6 Lining material. Press the V key, so the "LINING THICKNESS" is reversed from white to blue. Press the ENT key, lining thickness value entry can be performed.

The cursor can shift the numeric digit by the \bigcirc or \bigcirc key. The numeric can be entered by the \bigcirc or \bigcirc key.

After entry, press the (ENT) key.



LINING THICKNESS

2/4

(ENT

DECISION

3000 m/s


000.0<mark>1</mark> mm

Example) When the lining	g thickness is 1.25 mm:
LINING MATERIAL	LINING MATERIAL
MORTAR	MORTAR
LINING S.V.	LINING S.V.
3000 m/s	3000 m/s
LINING THICKNESS	LINING THICKNESS
000.0] mm	001.22 mm

7.8 Kind of fluid

Jump to 3/4 page with \checkmark of key. Select kind of fluid. For fluid having no entry, enter sound velocity. (Range: 500 to 2500 m/s or 1640 to 8202 ft/s) Press the \bigstar or V key, so the "KIND OF FLUID" is reversed from white to blue. Press the ENT key to display the "KIND OF FLU-ID" screen.

Select the kind of fluid by the () or () key. After selection, press the () key.



PROCESS SETTING				
KIND OF FLUID				
FLUID S.V.	WATER	~		
VISCOSITY		40 m/s		
SENSOR MOU				
	V METH	HOD 🔫		
DECISION)			
4	3/4			
ENT				

KIND OF FLUID WATER SEAWATER DIST. WATER AMMONIA ALCOHOL BENZENE BROMIDE ETHANOL GLYCOL KEROSENE		
SEAWATER DIST. WATER AMMONIA ALCOHOL BENZENE BROMIDE ETHANOL GLYCOL	WATER	
DIST, WATER AMMONIA ALCOHOL BENZENE BROMIDE ETHANOL GLYCOL	WATEN	
AMMONIA ALCOHOL BENZENE BROMIDE ETHANOL GLYCOL	SEAWATER	
ALCOHOL BENZENE BROMI DE ETHANOL GLYCOL	DIST. WATER	
BENZENE BROMIDE ETHANOL GLYCOL	AMMONTA	
BROMI DE ETHANOL GLYCOL	ALCOHOL	
ETHANOL GLYCOL	BENZENE	
GLYCOL	BROMIDE	
	ETHANOL	
KEROSENE	GLYCOL	
· · · · ·	KEROSENE	
	· · · · ·	

7.9 Viscosity

 \triangle

There is no need to change "1.0038E-6m2/s" when measuring water. Return the screen by pressing the 🔍 key.


Remarks


Dynamic viscosity coefficient is set to water (20°C). When measuring accurately or measuring fluid other than water, enter as needed. (See page 163, Table (29).) (Range: 0.001×10^{-6} to 999.999 × 10^{-6} m²/s)

Press the \bigcirc key, so the "VISCOSITY" is reversed from white to blue. Press the (ENT) key, you can enter the dynamic vis-

cosity coefficient. Move the digit by pressing the \bigcirc or \bigcirc key and enter numeric values by using the \bigcirc or \bigcirc key.

After entry, press the (ENT) key.







7.10 Selection of sensor mounting method


Mounting methods available for the sensor are V method and Z method as illustrated. To select the mounting method; Press the (▼) key, so the "SENSOR MOUNT" is reversed from white to blue. Press the (ENT) key. The "SENSOR MOUNT" screen will appear.

Select either V or Z method by the a or V key.

Remarks

Select the V method generally. Use the Z method in the following cases:

- Ample space is not provided.
- High turbidity
- Weak receiving waveform
- Thick scale is deposited on the pipe internal surface.




Z method

V method

7.11 Kind of sensor

Press the e key, so "SENSOR TYPE" is reversed from white to blue. Press the ent key to display the sensor type. Select any sensor from the type code of sensor to be used.

Select the sensor by the \bigcirc or \bigcirc key.






7.12 Transmission voltage (used when an indicator is 1 or less during measurement)


Press the \bigcirc key, so the "TRANS. VOLTAGE" is reversed from white to blue. Press the ENT key, the screen is ready to allow the selection of the transmission voltage level. Use the \bigstar or V key to select the level. Select "40Vpp" or "80Vpp" generally.

If the indicator cannot be set to MAX with the level at "160Vpp", ultrasonic wave may be attenuated due to contamination or scales deposited on the piping external and internal surfaces. Change measurement location.



The indicator will be updated on the measurement screen only.


If less than 2 indicators (intensity of receiving waveform) are displayed on the measurement screen, raise the transmission voltage.





7.13 Completion of PROCESS SETTING

After the settings are completed, press the \bigcirc key so "DECISION" is reversed from white to blue. Pressing the ENT key to complete settings, and then returns to the "SITE SETUP" screen. After mounting the sensor, perform zero point calibration.



Note) When the inner mounting diameter is 13mm, the sensor mounting method is 0.0mm or less depending on the pipe materials.


Necessary pipe thickness for fluid water [unit: mm (inch)]					
CARBON STEEL	2.1	(.085)	FRP	3.21	(.126)
STAINLESS STEEL	1.87	(.074)	DUCTILE IRON	2.15	(.085)
PVC	3.69	(.145)	PEEK	3.69	(.145)
COPPER	3.82	(.150)	PVDF	3.69	(.145)
CAST IRON	2.98	(.117)	ACRYLIC	2.70	(.106)
ALUMINUM	1.99	(.078)	PP	3.69	(.145)

When the sensor mounting length is 0.0mm or less, error of the measurement is approximately ± 2 to 5%.

8.1 Selection of mounting location


Detector mounting location, i.e., the conditions of the pipe subjected to flow rate measurement exert a great influence on measurement accuracy. So select a location meeting the conditions listed below.

- (1) There is a straight pipe portion of 10D or more on the upstream side and that of 5D or more on the downstream side.
- (2) No factors to disturb the flow (such as pump and valve) within about 30D on the upstream side.




Extracted from Japan Electric and Machinery Industry Society (JEMIS-032)

- (3) Pipe is always filled with fluid. Neither air bubbles nor foreign materials are contained in the fluid.
- (4) There is an ample maintenance space around the pipe to which the detector is to be mounted (see figure below).
 - Note 1) Secure an adequate space for allowing a person to stand and work on both sides of a pipe.
 - Note 2) D indicates the inside diameter of a pipe.




Space required for mounting detector


(5) The piping must completely be filled with fluid when it flows.



(6) For a horizontal pipe, mount the detector within ±45° of the horizontal plane.
 For a vertical pipe, the detector can be mounted at any position on the outer circumference.



(7) Avoid mounting the detector near a deformation, flange or welded part on the pipe.




8.2 Selection of detector


(1) Selection of mounting methods

There are 2 methods for mounting the detector; V method and Z method. For the mounting space, see the following sketch.

<Large/Medium sensor>




<Small diameter sensor, small sensor or high-temperature sensor>



Employ the Z method in the following cases.

- Mounting space need be saved (mounting space of the Z method is about one half of the V method's).
- Turbid fluid such as sewage is to be measured.
- Pipe has mortar lining.
- A thick film of scale may have been formed on the inner surface of pipe because it is old.
- In suficient received signal-strength with mounting detectors in V method while using maximum transmission voltage.



(2) Image figure of mounting dimension

(3) Detector selection standards

The Z method for large size sensor is recommended for outer diameter 300mm or more. PSX2-D should be used as much as possible for pipes such as old pipes, cast iron pipes, and mortar lining pipes, through which it is difficult for ultrasonic signals to pass.

Туре	Diameter	Temperatu	re
PSX2-B	13 100mm (V method)		+100°0
PSX2-A	50300mm (V method) 150400mm (Z method)	-40	+100°C
PSX2-HT	50250mm (V method) 150400mm (Z method)	-40	+200°C
PSX2-C	200600mm (V method) 2001200mm (Z method)	-40 +8	0°
PSX2-D	200 3000mm (V method) 6000mm 200 (Z method)	-40 +8	0°C


Detector

8.3 Use of surface-treated accessories

Eliminate pitting, corrosion, unevenness, etc. with paint thinner and sandpaper from the pipe portion where the detector is to be mounted.

Note) In case jute is wound on a pipe, it should be peeled off before the above treatment. When cast iron pipe is used, grind the sensor mounting surface by using a sander for smoothness.


Detector	Width
Small outer diameter PSX2-B	320 mm (12.6") or more
Small size (standard) sensor PSX2-A	540 mm (21.3") or more
Medium size sensor PSX2-C	Mounting dimension (L) + 200 mm (7.9") or more
Large size sensor PSX2-D	Mounting dimension (L) + 200 mm (7.9") or more
High temperature PSX2-HT	530 mm (20.9") or more



8.4 How to mount small size (standard) sensor and small outer diameter sensor to pipe

8.4.1 How to mount a sensor (V method)

 Loosen the lock nut and slide the sensor so as to meet the mounting dimension and then tighten the nut.




After cleaning the surface of the pipe, the sensor should be mounted




Apply a small quantity (like toothpaste) of silicon grease to the transmitter unit.

- (3) Fix the both ends (saddles) of the sensor to the pipe by cloth belts.
 Mounting will be facilitated by winding the cloth belts on the pipe in advance.
 Cloth belts are usable at 80°C or lower. If beyond 80°C, stainless steel belts should be used. (High-temperature stainless steel type of belt)
- (4) Make sure the sensor is mounted in parallel with the pipe axis and the mounting dimension is right. Then, turn the element holder clockwise until the sensor comes in close contact with the pipe.

Stop turning the element holder when it stiffens because the transmitting surface comes in contact with the pipe surface. Be careful not to turn the holder excessively.




8.4.2 How to mount a small size (standard) sensor (Z method)



(5) Make sure that the sensor is mounted in parallel with the piping and that the mounting position is correct. Then, turn the element holder clockwise until the sensor is firmly fitted to the piping.

Stop turning the element holder where the transmitting surface contacts the surface of pipe, and thus the element holder will not rotate.

Do not turn it excessively.



8.5 How to mount large and medium size sensor

8.5.1 How to determine mounting position

Determine the mounting position by carrying out the following work. For this work, gauge paper is necessary (For the gauge paper, refer to page 57).

- Match the edge of gauge paper with the line at about 100mm (3.9") from one end of the pipe portion treated for detector mounting, and wind the gauge paper so that the line marked on the paper is parallel with the pipe axis (fix with tape not to allow deviation). At this time, the edge of gauge paper should be aligned.
- (2) Extending the line marked on the gauge paper, mark straight line A on the pipe.
- (3) Mark a line along on edge of the gauge paper. The intersection of this line and straight line A is replaced with A₀.
- (4) In mounting by the V method, peel the gauge paper and measure the mounting dimension from A₀ to determine A₂ position. At this position, mark a line orthogonal to the straight line A.


A₀ and A₂ become the mounting positions.


Example) L = 200mm (7.9")


- (5) In mounting by the Z method, measure the circumference from A₀ with a measuring tape. At 1/2 of the circumference, determine points B₀ and B₁, and mark a line (straight line B) connecting those points.
- (6) Mark the points B₀ and peel off the gauge paper. Measure the mounting dimension from B₀ to determine B₂ position. At this position, make a line orthogonal to the straight line B.


 A_0 and B_2 become the mounting positions.


Example) L = 100mm (3.9")














8.5.2 How to connect medium size sensor for PSX2-C type only

(1) Remove the sensor cover.


- 🗥 Caution -


Be careful not to cut your hands or etc. by the cover.

(2) Mount the sensors so that the upstream and downstream sensors can be distinguished from each other.

Remove the cable clamp.

Note) In case of removing the cable clamp, be sure not to lose the nut.






(3) Insert the coaxial cable through the cable lead-in port.

loosen the terminal screws (G, +).

Connect core line white to (+), shield wire to (G).

Note) At this time, remove the resistor.

For connecting coaxial cable to terminal, turn the power off.



(4) Secure the coaxial cable with the cable clamp.




(5) Put the cover on the detector.



8.5.3 How to connect large size sensor for PSX2-D type only

(1) Slide the detector cover slightly. Remove the cover with a driver.

- (2) Determine the mounting position of sensor on the pipe.Align the transmission direction marks.
- (3) Put a mark on the inlet of coaxial cable. When the pipe is horizontally installed with the detector, allow the coaxial cable to be suspended to prevent entry of water from the cable inlet. When the pipe is installed vertically, it does not matter how the coaxial cable should be installed.
 - Note) Upstream and downstream sensors should be able to be identified.
- (4) Connect the coaxial cable to terminal (G, +) and fix it with the cable clamp.Connect core line white to (+), shield wire to (G).



Cover

(5) Install the cover.




- Be careful not to cut your hands or etc. by the cover.
- For connecting coaxial cable to terminal, turn the power off.

8.5.4 Mounting of medium type sensor on pipe

Mounting the detector using the following procedure.

- Provide wire rope for the upstream and the downstream detectors.
 Make sure that the length of the wire rope is longer than the circumference of the pipe.
- (2) Lay the wire rope around the pipe at the position of the upstream detector.Then hook the mounting spring into the wire rope.
- (3) Spread silicone filler over the whole transmitting side of the sensor.


Care should be taken to prevent entry of air bubbles.









(4) After cleaning the surface of the pipe, the sensor should be mounted.




(5) Spread the wire rope near the marked lines in the left-right direction, bring the sensor in close contact and fit the wire rope. Make sure that the matching mark on the sensor is aligned with the marking line.



- (6) Make sure that the center mark on the sensor is aligned with the marking line. Then, connect the coaxial cable to the transmitter.
 - Note) Do not pull the coaxial cable. If it is pulled, the sensor is shifted which results in incorrect measurements.



(7) After mounting the upstream sensor, mount the downstream sensor in the same way. The figure is for mounting by the Z method.



8.5.5 How to mount large size sensor to pipe

(1) Height adjustment of guide plate

- Place the sensor on the pipe surface in parallel with the pipe axis.
- Loosen the guide plate fixing screw and slide the guide plate until its edge and transmitting surface touch the surface of pipe.
- Then tighten the fixing screw.

(2) How to determine the length of wire rope

- Place the sensor on the marked lines and fit the wire rope and fastening spring.
- Loosen the wire clip and pull the wire rope until the overall length of fastening spring approximates 180mm (7.1"). Then tighten the wire clip.


(The fastening spring has a free length of 110mm or 4.3")


• While fixing the wire rope, remove the sensor.

(3) Mounting of sensor

- Wipe off contaminates from the transmitting surface of sensor and the sensor mounting surface of pipe.
- Apply the silicone grease on the transmitting surface of sensor wile spreading it evenly.
- Film thickness of the silicone grease should be about 3mm.
- Spread the wire rope near the marked lines in the left-right direction, bring the sensor in close contact and fit the wire rope.
- Align the matching mark of sensor with the marked line. In addition, make the transmitting direction marks of sensors face each other.
- Make sure the matching mark of sensor is aligned with the marked line and connect the coaxial cable to the converter.
- Note) Do not pull the coaxial cable. Otherwise, the sensor will be activated to disturb measurement.








8.6 How to mount high temperature sensor to pipe

8.6.1 How to mount a sensor (V method)

(1) Loosen the lock nut and slide the sensor so as to meet the mounting dimension and then tighten the nut.



Cable

(2) Apply a coat of grease for high temperature to the transmitting surface of the sensor. Spread the compound over the entire area. Keep the sensor retracted by turning the element holder counterclockwise. After cleaning the surface of the pipe, the sensor should be mounted.

(3) Fix the both ends (saddles) of the sensor to the pipe by stainless belts.

(4) Make sure the sensor is mounted in parallel with the pipe axis and the mounting dimension is right. Then, turn the element holder clockwise until the sensor comes in close contact with the pipe.


Stop turning the element holder when it stiffens because the transmitting surface comes in contact with the pipe surface. Be careful not to turn the holder excessively.

\land CAUTION -

Be careful not to cut your hands or etc. by the stainless belt.

8.6.2 How to mount a sensor (Z method)


Remove saddle set screws at 4 locations, and remove a saddle and a sensor unit out of the frame.
 Also, remove a saddle on the guide rail for high temperature sensor (option).




(3) Spread high-temperature grease over the whole transmitting surface of the sensor.

> Turn the element holder counterclockwise to return the sensor. After cleaning the surface of the pipe, the sensor should be mounted.

(4) Mount each sensor individually on the marking line.




(5) Make sure that the sensor is mounted in parallel with the piping and that the mounting position is correct. Then, turn the element holder clockwise until the sensor is firmly fitted to the piping. Stop turning the element holder where the transmitting surface contacts the surface of pipe, and thus the element holder will not rotate. Do not turn it excessively.



8.7 How to fold gage paper (used for determining mounting position)

- (1) Prepare a sheet of paper (vinyl sheet) of 4 D or more in length and 200 mm (7.9") or longer in width (D is preferable) as shown below.
- (2) Draw a line intersecting at right angles with the longest sides about 100 mm (3.9") from one paper end.




Bulletin F-9-PUX2 9. START MEASURING

When wiring, piping settings and mounting of the sensor are completed, start the measurement. The contents displayed on the measurement screen are as follows.

On the measurement screen, instantaneous flow, instantaneous flow velocity, integrated flow rate, analog output, and analog input are displayed.
Of the 3 stages displayed on the MEASURE screen, contents can be arbitrarily allocated. Allocation is accomplished by selection of "measurement kind (flow rate, velocity, total, etc.)".
If the flow rate is displayed when water flow stops, refer to page 66, "ZERO ADJUSTMENT" and page 72, "CUT OFF".

If the flow display fluctuates, refer to page 70, "DAMPING".

- Integrated flow rate value is available in the range from 000000000 to 9999999999. If the value exceeds 99999999999, it returns to the preset value.
- Move the cursor on the measurement screen using the (\bullet) , (\bullet) , (\bullet) and (\bullet) keys.



(1) Clock

This instrument has a timer function. Refer to "10.3.1(1) Clock" function to set the time. The timer function should be used based on this clock.

(2) Memory card

Displays the memory card loading status.

- : When the memory card is not set.
- **SD** : When the memory card is set.
- **SO** : When the memory card is filled up
- **SO** : When the memory card is write protected.
- **Sf** : When the memory card is write-protected and being filled up.

(3) Measurement mode

Displays the current measurement mode.

() : Measured by the transit time method.

Indication at heat quantity measurement (icon color indicates the status).

- Black: No heat quantity measurement (Example: 🕥)
- Blue: Heat quantity measurement, cooling operation (Example: ())
- Red: Heat quantity measurement, heating operation (Example: 🕥)

For measuring heat flow, refer to "10.3.3 CALORIE MODE" function.

(4) Analog input/output

Display the usage state of analog input and output.

For using analog input or output, refer to "10.3.2 analog input/ output" function.

- (Analog input/output valid
- 💦 : Analog input/output invalid

(5) Indicator

Shows the intensity of ultrasonic receiving signal. Displays with 4-level.

If the signal is weak, refer to "7.12 Transmission voltage" and raise the transmission voltage level.

-)) : With signal (max.)
-) : With signal
-)) : Signal decay
- 🔉 : Without signal

(6) Battery status

Displays the remaining charge of battery.

For charging the built-in battery, refer to (1) Energizing with built-in battery in "5.1 Operating power supply".

Power will be turned off in 40 minutes after battery shortage is displayed. (The time may be affected by ambient temperature, the operating condition, or the battery condition.)

- : Charged
- : Battery level 2
- 🚺 : Battery level 1
- : Battery shortage

(7) Site name

Displays the name of the operated site.

(8) Quick logger

Logger can be started from the measurement screen. For logger function by timer operation, refer to "10.2.3 LOGGING".

Note) It cannot be started during data logging.

Logger started

🙀 : Logger stopped

Cannot be started

(9) Status display

Displays the current status. In case more than one error is displayed, the **()** is indicated at the far right.

Check if "NORMAL" is displayed. If the sensor is not connected, other messages may be displayed. This is not an error.

In case another message is displayed after installing and connecting the sensor, take corrective actions according to page 140, "10.8 Contents of error in status display".

If "NORMAL" is not displayed when 1 or less indicator is display, refer to page 147, "12.3 Error in measured value".

(10) Kind of measurement

When changing the kind of measurement on the measurement screen:

Flow rate, velocity, total display can be changed on the measurement screen.

- Move the cursor to the measurement screen to be changed.
- Press the ENT key, and the screen appears, enabling the kind of measurement to be selected. Select any kind of measurement by the or key and then press the ENT key.

(11) Flow rate

When changing the flow rate on the measurement screen:

Unit of flow rate may be changed on the measurement screen.

- Move the cursor to the unit of flow rate to be changed.
- Pressing (or) key, move the cursor to the unit of flow rate you want to change.
- Press the (ENT) key, and the screen appears, enabling the unit of flow rate to be selected.
 Select any unit by pressing the (or (key and then press the (ENT) key.

2008/01/31 17:01 SO A M III (default) Second Velocity FLOW RATE Velocity FLOW RATE FLOW RATE FLOW RATE(%) +TOTAL(ACTUAL) VELOCITY -TOTAL(ACTUAL) ANALOG INPUT 2 +TOTAL(ACTUAL) m³ 330.12 E2:NO SIGNAL

2008/01/31 17:02 💼 🕤 🗛 🚴 🎹			
(default)			
FLOW RATE	m³∕h		
	m³/d km³/d Mm³/d	80	
VELOCITY	BBL/s	-	
+TOTAL(ACTUAL	BBL/min BBL/h BBL/d KBBL/d MBBL/d)08 ■■ 12	
E2:NO SIGNAL			

(12) Unit of total

When changing the unit of total, refer to page 67 "UNIT OF OUTPUT".

(13) Changing decimal position

Decimal place can be changed. Decimal position can be changed on the measurement screen.

- For modification method, move the cursor by pressing ♥ or ▲ key.
- Press the ENT key, the decimal position can be changed. (The ends of cursor color will thicken up)
- Pressing 🕥 or 🌢 key, select the changing position, and then press the ENT key.

(14) Switching measurement screens


2008/05/14 11:13 💁 🕞 📎 🐠 🎹 (default) FLOW RATE m³⁄h 0.055 Changing decimal position VELOCITY m/s 0.004◀ +TOTALIZER mL 322.7 NORMAL

The measurement value screen can be switched to the measurement graph screen.

Move the cursor to the \bigoplus and press the (ENT) key.

The screen switches as shown below.


Follow the same steps described above to return to the previous measurement value screen.



Scale setting can be changed on the measurement graph screen.

Move the cursor to the $\boxed{1}$ and press the (ENT) key.

Select the item by the \bigcirc or \bigcirc key and press the ENT key to change the setting. Use the \bigcirc or \bigcirc (\bigcirc key for entering and press the ENT for setting. Pressing the ESC key returns to the original status.



(15) Status display of total

It allows you to start/stop the total process on the "MEASUREMENT" screen.


Refer to "10.1.5 TOTAL" about the totalizing function by timer operation.

Move the cursor to the \bigcirc or \square and press the \bigcirc key.

The total process can be made in the "TO-TAL".

• : START: Totalizing in progress

: STOP: Not totalized




(16) Total reset

The total value can be set to 0.

Move the cursor to the \square and press the (ENT) key to reset the total value.

10.SETTING OPERATION (APPLICATION)

This section describes an outline and page configuration of each function page. Various function pages are called up from the menu screen.



Note) For flow velocity distribution within option, refer to "10.7 Flow velocity distribution display function (option).

10.1 How to use SITE SETUP function (SITE SETUP page)


10.1.1 SITE MEMORY: when registering data which are set and calibrated on the page

"SITE MEMORY" allows you to register data which are set and calibrated on the "SITE SETUP" page to the memory of the main unit.

When measurements are performed repeatedly in the same pipe, registered data can be loaded to help you in achieving measurements. Up to 32 registrations of data can be made to the memory.


Registration data: Establish setting, zero point adjustment, unit of output, output control.

[Operation]



(2) Move the cursor to "MODE" and press the ENT key. The mode selection screen will appear.


When pressing the (ENT) key after mode selection, the relevant mode is determined.




(3) Select "SELECTION" to read out the

data, "REGISTRATION" to register the data and "DELETE" to delete the data.

• For selecting "SELECTION", select a name of a site by using the cursor and press the ENT key. So, this function enables you to load the data.




• For selecting "REGISTRATION", move the cursor to an empty field of NAME and press the (Refer to "7.2 Entry of site name" for details.)



• For selecting "DELETE", select the name of the site to delete by using the cursor and press the ENT key. Select "YES" on the screen and press the ENT key. So, this function enables you to delete the data.

Note: Be careful since pressing "YES" deletes the PROCESS SETTING data you registered.



10.1.2 ZERO ADJUSTMENT: when performing zero adjustment

On this screen, zero point is set or cleared.

[Operation]

- Select "ZERO ADJUSTMENT" by the ▲ or ♥ key and press the ENT key. The zero adjustment screen will appear.
- (2) Select ZERO ADJUSTMENT, and press the ENT key. Zero adjustment to be specified is carried out.

• [SET ZERO]

Perform zero adjustment in situation where the flow is stopped.

The measurement indication should be at zero when the (ENT) key is pressed.


This zero calibration operation should be performed after stopping flow.


• [CLEAR]

Adjustment is cleared.



When PROCESS SETTING or measurement method (page 93) is changed, perform zero adjustment.







10.1.3 UNIT OF OUTPUT: when changing unit of each output

This function enables you to set unit of flow rate, total, temperature and total heat quantity.

Flow rate unit: Select the unit of flow rate and output range. Metric system: L/s, L/min, L/h, L/d, kL/d, ML/d, m³/s, m³/min, m³/h, m³/d, km³/d, BBL/s, BBL/min, BBL/h, BBL/d, kBBL/d, MBBL/d English system: gal/s, gal/min, gal/h, gal/d, kgal/d, Mgal/d, ft³/s, ft³/min, ft³/h, kft³/d, Mft³/d, BBL/s, BBL/min, BBL/h, BBL/d, kBBL/d, MBBL/d Flow rate total: Select the unit of flow rate. Metric system: mL, L, m³, km³, Mm³, mBBL, BBL, kBBL English system: gal, kgal, ft3, kft3, Mft3, mBBL, BBL, kBBL, ACRE-ft Temperature: Select the unit of temperature input. Metric system: °C, K English system: F, K Heat flow: Select the unit of heat flow and output range. MJ/h, GJ/h, BTU/h, kBTU/h, MBTU/h Thermal total: Select the unit of total thermal. MJ, GJ, BTU, kBTU, MBTU Note) For the change of SYSTEM UNIT, refer to "10.3.1(2) SYSTEM UNIT".

Direction of selected unit


	Display	Logger	Printer
Flow rate unit		0	0
Flow rate total	0	0	0
Temperature	0	0	0
Heat flow	0	0	0
Thermal total	0	0	0

O: The unit selected by the unit of output is used.


□: The unit selected by measurement screen is used.

[Operation]

 Press the ▲ or ♥ key on the SITE SETUP page and select "UNIT OF OUTPUT". Then, press the ENT key.



(2) Press the ▲ or ♥ key and move the cursor to the output item of which unit to be changed.



 (3) Press the ^{ENT} key to open the unit selection screen. Select the unit by the ▲ or ♥ key and then press the ^{ENT} key.


UNIT OF OUTPUT	
FLOW UNIT	
L/s	
L/min	
L/h	
L/d	
kL/d	
ML/d	
m³/s	
m ³ /min	
m ³ /h m ³ /d	

10.1.4 OUTPUT CONTROL: when controlling measured value (output control function)

This function enables you to set the value of damping, output calibration and low flow rate cut off.

[Operation]

 Press the ▲ or ♥ key on the SITE SETTING page and select "OUTPUT CONTROL". Then, press the ENT key and the OUTPUT CONTROL screen is displayed.



(2) Press the

 (2) Press the

 (2) or

 (2) key and move the cursor to the item of which output control setting to be changed, and then press the


 (ENT) key.

OUTPUT CONTROL		
DAMPING		
	5.0	sec
CALIBRATION ZERO		
	0.000	m/s
CALIBRATION SPAN	100.00	٥
CUT OFF	100.00	/0
	0.000	m/s

For details of output control, refer to the items described in the following pages.

- For damping, refer to (1) "DAMPING": when attenuating the variation of measured value.
- For output calibration, refer to (2) "OUTPUT CALIBRATION": when calibrating measured value.
- For low flow rate cut, refer to (3) "CUT OFF": output cut off at low flow rate.


(1) "DAMPING" : when changing output response




[Operation]

Press the ▲ or ♥ key on the OUTPUT CONTROL screen and select "DAMPING". Then, press the ENT key, and the cursor moves to the set item, enabling you to set the response time.





(2) OUTPUT CALIBRATION ZERO/SPAN: when calibrating measured value (output calibration function)



[Operation]

Press the ▲ or ♥ key on the OUTPUT CONTROL screen and select "CALIBRATION ZERO" or "CALIBRATION SPAN". Then, press the ENT key, and the cursor moves to the set item, enabling you to make zero/span setting.


OUTPUT CONTROL		
DAMPING		
	5.0	sec
CALIBRATION ZERO		,
CALIBRATION SPAN	0.000	m/s
CALIENATION SPAN	100.00	q
CUT OFF	100.00	<i>1</i> 0
	0.000	m/s

(2) Press the

 or

 key to move the digit, and use the
 or

 key to enter a numeric value. After entry, press the (ENT) key for setting.



– \triangle Caution -


As output is corrected, measured value changes.

It is recommended to set as follows unless correction is required.

Zero point: 0.000 m/s Span point: 100.00%


(3) CUT OFF: output cut off at low flow rate (low flow cutoff function)

When flow rate is extremely low, its output can be cut off. (range: 0 to 5.000 m/s or 16.4 ft/s) If fluid in the pipe is moving due to convection, etc., even though the valve is closed, this flowmeter outputs a measured value. Therefore, values below an appropriate level should be cut off.



[Operation]

Press the ▲ or ♥ key on the OUTPUT CONTROL screen and select "CUT OFF". Then, press the ENT key, and the cursor moves to the set item. Output cut off point is settable.



(2) Move the digit by pressing the

 or
 key and enter a numeric value by pressing the
 or

 key. After entry, press the

 key.

OUTPUT CONTROL		
DAMPING		
	5.0	sec
CALIBRATION ZERO	0.000	- (a
CALIBRATION SPAN	0.000	1178
	100.00	%
CUT OFF		
	0.000	m/s

10.1.5 TOTALIZER: when performing the total process of measured data (totalize)

Total process and setting of total output can be performed.

(1) To start/set total output

[Operation]

Select "TOTALIZER" on the SITE SETUP screen by pressing the or key.
 Press the key to display the total output selection screen.

- (2) Pressing the ENT key enables you to select the total output mode.
 Select the mode from MANUAL, QUICK, and TIMER by pressing the or key.
 (For details of MODE, refer to description of the mode in the following page.)
- (3) Move the cursor to "START" by the ▲ or ♥ key, and then press the ENT key. The total will start.

(4) To stop the total output in the middle, move the cursor to "STOP" and press the ENT key.
"STOP" is also possible from the totalizing calculation display button on the measurement screen.

Total will not start unless the cursor is pointed to "START" and the (ENT) key is pressed. In timer mode, start time and date must be in the future compared with the time and date of the system clock. To change the system clock, refer to page 88.



Mode Description		
"MANUAL" mode:	Instant total starts Without choosing STOP, total continues.	TOTALIZER MODE <u>SETTING</u> MANUAL QUICK TIME <u>00:30</u> TIMER START TIME 2008/04/24 17:50 START START
"QUICK TIME" mode:	Total starts after the time of set- ting, total is performed within the time selected from the menu, and it stops automatically after the time passed. • 30min • 1hour • 1hour • 1hour 30min • 2hour	OCTAL IZER QUICK TIME 00:30 01:00 01:30 02:00 02:30 03:00
"TIMER" mode:	 3hour Set the time of total to start and stop. After each time is set, total starts and stops automatically. 	TOTALIZER MODE <u>SETTING</u> ○ MANUAL ○ QUICK TIME <u>00:30 ▼</u> ④ TIMER START TIME 2008/04/24 17:00 STOP TIME 2008/04/24 17:50

2008/04/24 17:50

START

Bulletin F-9-PUX2

SETTING

HOLD

0.000

0.000

~

10 sec

TOTALIZER

MODE

TOTALIZER PRSET

BURNOUT (TOTAL)

BURNOUT TIMER

TOTAL(THERMAL) PRSET

(2) To set total output

 Move the cursor to "SETTING" on the TOTAL screen by the or key.

Pressing the (ENT) key enables you to select the set item by the (A) or (V) key.

Press the (ENT) key to make setting. (See the following.)

"TOTALIZER PRESET":

Preset the flow rate total to restart total. [Settable range: 0.000 to 999999999]

"TOTAL (THERMAL) PRESET":

Preset the total heat quantity to restart total.


[Settable range: 0.000 to 999999999] Resetting actual integral values should be performed on the measurement screen.

(See Page 58)

"BURNOUT (TOTAL)": Determines how to dispose of the total when the measurement status is abnormal on account of an empty pipe interior or bubbles mixed in fluid. Settable range HOLD: Stops total (as factory set) NOT USED: Continues total according to a flow rate marked immediately before the error occurrence. TOTALIZER MODE SETTING TOTALIZER PRSET 0.000 TOTAL(THERMAL) PRSET 0.000 BURNOUT(TOTAL) HOLD ▼ BURNOUT TIMER 10 sec

TOTALIZER	
OUTPUT BURNOUT	
NOT USED	
HOLD	

"BURNOUT TIMER": Sets the time from error occurrence to error processing. [Settable range: 0 to 900sec (factory set: 10sec)] The total continues until the burnout timer is actuated.




10.2 Setting of data logger function

This function allows you to save measured values to the SD memory card, call the measured data saved in the memory after measurement is completed, display, and produce output of data on a printer.

Recording capacity: Depends on capacity of the SD memory card.

(1) How to view data logger


Call the logged measurement data, make the setting on graph display and print output.



Up to 100 items can be viewed by using the cursor. For 100 or more, check SD memory card directly by your PC.

(2) How to view logging screen

This is the screen to set the stored file name, kind of measurement data and operation mode which is stored to SD memory card.



76

10.2.1 "Logger Operation" mode


There are two logging modes, i.e., quick logger that permits operation from the measurement screen and logger that is set from the menu screen. Logger is of two different modes, i.e., continuous mode and appointed time mode.

- Quick logger
- Logger
 - (1) Continuous mode
 - (2) Appointed time mode

(1) Quick logger

The quick logger starts when quick logger start button **us** in the measurement screen is pressed. The quick logger exits when a period of an hour has elapsed since it was started or when quick logger stop button is pressed.

- Logging time: 1 hour, fixed
- Cycle: 10 seconds, fixed
- Measured data type: 3 types (unit and number of digits after decimal point are the same) displayed in measurement screen and status display



(2) Logger

(1) Continuous mode


Continuous mode is the mode to perform logging in a fixed period from start date and time to exit date and time.

Exit occurs upon elapse of exit date and time or when the stop button is pressed. As the exit time varies by the start time and period, there are cases where it is different from the set exit time.

- Logging time: Start date and time to exit date and time
- Cycle: 10 seconds to 24 hours
- Measured data type: 14 measured data types and status display

Example) Case of setup of logging from 9/1 9:00PM to 9/8 4:00AM

- Start date and hour: 2008/09/01 21:00
- Exit date and hour: 2008/09/08 04:00



(2) Appointed time mode

Appointed time mode is the mode to perform logging in a fixed period only during a certain time zone of a day between the start date and exit date.


Exit occurs upon elapse of exit time of exit period or when the stop button is pressed. As the exit time varies by the start time and period, there are cases where it is different from the set exit time.

The difference between start time and exit time is one hour at minimum. If the start time is earlier than the exit time, logging is performed over 0 o'clock.

- Logging period: Start date to exit date
- Logging time: Start time to end time
- Period: 10 seconds to 23 hours
- Measured data type: 14 measured data types and status display

Example) Case of setup of logging for one week from 9/1, from 9:00PM to 4:00AM

- Period: 9/1 to 9/8
- Start date and hour: 21:00
- Exit date and hour: 04:00



(3) Measured data type

The measurement data is following 14kind.

VELOCITY FLOW RATE FLOW RATE (%) +TOTALIZER -TOTALIZER AI CHANNEL 1 AI CHANNEL 2 FEDDING TEMP. RETURNING TEMP. DIFFEREN. TEMP. THERMAL FLOW THERMAL FLOW (%) +TOTAL (THERMAL) -TOTAL (THERMAL)

10.2.2 Logger data file format

One logger file is composed of files of two types indicated below. The data file is stored as divided by 65,500 lines for permitting high-speed access and due to restrictions in the maximum number of lines of CSV display of Microsoft Excel.

File type	File name	Remarks
Configuration file		Means logger start time and relevant logger
Data file		data files. Logging data in a specific period

The maximum number of data files in a logger is 20 files in case of a continuous logger, and is 550 files in case of an appointed time logger. The appointed time logger is of one file per day. Note) After reaching the maximum data file, the logging will be stopped.

The logger data list shows the following names excluding extension (.ini) of logger configuration files.

- Logger ... "Logger name_(start date)_(start hour)"
- Quick logger ... "QUICK_(start date)_(start hour)"

If capacity shortage arises during logging operation, logging operation stops with the following screen displayed.

When this screen appears, replace the SD memory card immediately.

Press the (ESC) key, or remove SD memory card, the message will be cleared.

Move the cursor to "STOP" to stop logging, press the (ENT) key, and once remove the memory card.




10.2.3 LOGGING: when logging (recording) measured data

"LOGGING" only sets logging conditions.

To start logging, follow the steps (2) to (8) given shown below.

[Operation]

 Press the ▲ or ♥ key on the LOGGING screen to select "LOGGING" and press the ENT key.



(2) Register the name of the logger.Press the ENT key after the cursor is placed in the "NAME".


The cursor moves to the character entry field.

(3) Register the place or the pipe name for logging. Refer to Page 24 and 25 to enter characters.

(4) Select the kind of data to be logged.
Move the cursor pointed from "NAME" to "KIND"
by the \bigcirc key.
Then, press the (ENT) key, and the cursor moves to
kinds of data.


NA	ME		Ĺ	K	IN	D		ſ	M	OD	E	
	_	_	_	_	_	_	_	_	_	_	_	
N C a b) C) P	Q d q	R e r	S f s	T g t	U h u	v i v	₩ j ₩	X k ×	γ 1	Z	
BS	CA	٩N	E	ENI)	_	_	_	_	_	_	


LOGG	N	a										
NAM	E		Ĺ	K	IN	D		Ĺ	M	OD	Е	
P L T	[2											
ΑB	С	D	Ε	F	G	Н	I	J	К	L	M	
NO	Ρ	Q	R	S	Т	U	۷	W	Х	Y	Ζ	
аb	С	d	е	f	g	h	i	j	k	1	M	
no	р	q	r	8	t	u	۷	W	Х	У	Ζ	
12	3	4	5	6	7	8	9	0	Q	_		
BS	Cł	٩N	ł	ENI)							



(6) After selection, return the cursor to "KIND" by the (ESC) key.

(8) Press the ENT key, and the cursor moves to "CON-TINUOUSNESS".
Then, press the ▶ key to move the cursor to "AP-POINTED TIME".









– vert Caution -

- Do not remove the memory card while data is written in it. Otherwise the logger data can not be read.
- Do not turn the power off during reading the data to memory card. Otherwise the logger data can't be read.

- (9) Press the ENT key to move the cursor to the set item "CONTINUOUSNESS" or "APPOINT TIME".
- Setting of "CONTINUOUSNESS"
 Sets the start time, the finish time, and the logging cycle.
 Move the cursor to "START" and press the *ENT* key to start logging.
- Setting of "APPOINT TIME" Sets the logging period, the start/finish time, and the logging cycle. Move the cursor to "START" and press the *key* to start logging.

LOGGING	
NAME Y	KIND MODE
CONTINUOUS	APPOINT. TIME
START TIME	
	2008/04/24 17:29
STOP TIME	2008/04/24 18:19
CYCLE	2000/04/24 10.13
	00:00:10
START	

LOGGING			
NAME Y	KIND	ľ	MODE
CONT I NUOUS,	. AP	POIN	T. TIME
PERIOD			
2008/04	4/24 -	200	8/04/24
START TIME			
OTOD TIME			00:00
STOP TIME			00:00
CYCLE			00.00
UTULL		0	0:00:10
START			
SIAKI			

- If the output unit or system unit was changed after logger start, logging is performed in the unit at the time of start. The changed unit becomes valid after the logger is stopped.
- Start-up is not permitted if the set time is later than the time of the main unit clock. Make sure to set a time with a margin of several minutes after the present time.

10.2.4 "LOGGER DATA": when checking or printing logged data


(1) When checking logged data on screen

[Operation]

(ENT) key.


 Press the ▲ or ♥ key on the LOGGER screen, select "LOGGER DATA" and press the ENT key.


(2) When the LOGGER DATA screen appears, press the




LOGGER DATA			
(de	fault)		
MO	DE GRAPH DISP. 💌		
CA	PACITY 20.172 Mbyte		
AV	AILABILITY 222.703 Mbyte		
No	LOGGER DATA		
1	AAAAAAAAAA_20080421_195200		
2	TEST_20080416_213000		
3	A_20080415_213400		
4	QUICK_20080424_183046		
5	QUICK_20080425_084538		
6	AAA_20070101_030000_1		
7	eee_20070101_030000		
8	QUICK_20071227_163113		
9			
10			

(3) The MODE screen appears. Select "GRAPH DISP." and press the ENT key.








Mode Description



- (5) To change kind of data to be displayed:
 Move the cursor to "SOURCE" and press the ^[ENT] key to enter the SOURCE screen. Select the unit by pressing the or v key.
 - Note) Displays only types of logged data.








Move the cursor to "ZOOM" to enlarge or contract the time axis by the \bigcirc or \bigcirc key.

data axis (vertical axis):

(6) To change scale of time axis (horizontal axis) and

Enlarge or contract the data axis by the \bigcirc or \bigcirc key.




(2) When printing logged data in text


[Operation]


- (1) Press the ▲ or ♥ key on the LOGGER screen, select "LOGGER DATA" and press the ENT key.
- (2) When the "LOGGER DATA" screen appears, press the (ENT) key.


(3) The MODE screen appears. Select "PRINT" and press the (ENT) key.

(5) Set the printing conditions. Then, move the cursor to "PRINT" and press the KIT key.










[Example]

306 data are saved in the "NPR3" logger data every 30 seconds between 19:47 and 21:45 (o'clock). The logger data from the 10th (at 19:52) to the 300st (at 21:42) are printed out every 60 seconds.




10.3 Setting of system (SYSTEM SETUP screen)

This system allows you to accomplish the BASIC SETUP (system setup such as setup of clock and measurement unit), the ANALOG INPUT/OUTPUT (analog input setting and input/output calibration) and the CALORIE MODE (setting of mode, operation and temperature).


10.3.1 BASIC SETUP: when setting the system

(1) Select "BASIC SETUP" on the SYSTEM screen. Press the ENT key to display the BASIC SETUP screen.



(1) "CLOCK": when setting the clock (set the present time)


(1) Press the ▲ or ♥ key on the BASIC SETUP screen and select "CLOCK".
Press the ENT key, and the cursor moves to "DATE DISPLAY".
Press the ENT key to display the Date DISPLAY screen.
Select the display of date by the ▲ or ♥ key, and press the ENT key.
YYYY: Year
MM: Month
DD: Day



BASIC SETUP	
1 CLOCK	1
DATE DISPLAY	
SET DATE/TIME 2008/01/09 14:14	
]
SYSTEM UNIT	1
METRIC -	I
0 min	
1/2 🕨	

(2) Move the cursor to SET DATE/TIME by the or
 (2) Move the cursor to SET DATE/TIME by the or
 (2) Move the cursor to SET DATE/TIME by the or
 (2) Move the cursor to SET DATE/TIME by the or
 (2) Move the cursor to SET DATE/TIME by the or
 (2) Move the cursor to SET DATE/TIME by the or
 (2) Move the cursor to SET DATE/TIME by the or
 (2) Move the cursor to SET DATE/TIME by the or
 (2) Move the cursor to SET DATE/TIME by the or
 (2) Move the cursor to SET DATE/TIME by the or
 (2) Move the cursor to SET DATE/TIME by the or
 (3) Move the cursor to SET DATE/TIME by the or
 (4) Move the cursor to SET DATE/TIME by the or
 (4) Move the cursor to SET DATE/TIME by the or
 (5) Move the cursor to SET DATE/TIME by the or
 (5) Move the cursor to SET DATE/TIME by the or
 (5) Move the cursor to SET DATE/TIME by the or
 (5) Move the cursor to SET DATE/TIME by the or
 (5) Move the cursor to SET DATE/TIME by the or
 (6) Move the cursor to SET DATE/TIME by the or
 (7) Move the cursor to SET DATE/TIME by the or
 (7) Move the cursor to SET DATE/TIME by the or
 (7) Move the cursor to SET DATE/TIME by the or
 (8) Move the cursor to SET DATE/TIME by the or
 (7) Move the cursor to SET DATE/TIME by the or
 (8) Move the cursor to SET DATE/TIME by the or
 (8) Move the cursor to SET DATE/TIME by the or
 (8) Move the cursor to SET DATE/TIME by the or
 (8) Move the cursor to SET DATE/TIME by the or
 (8) Move the cursor to SET DATE/TIME by the or
 (8) Move the cursor to SET DATE/TIME by the or
 (8) Move the cursor to SET DATE/TIME by the or
 (9) Move the cursor to SET DATE/TIME by the or
 (9) Move the cursor

Setup contents 2008/02/01 10:03 (year, month, day, hour, minute)



When using the total data logger or the timer function of the printer, time setting can not be operated. Stop the timer function, and then set it again.

(2) SYSTEM UNIT: when setting the measurement and setting unit system [selection of meter system and inch system]

[Operation]

Select "SYSTEM UNIT" by the ▲ or ♥ key on the BASIC SETUP screen.
 Press the ENT key, and the SYSTEM UNIT screen is displayed.

BASIC SETUP
CLOCK DATE DISPLAY SET DATE/TIME 2008/01/09 14:14
SYSTEM UNIT LCD POWER OFF
1/2 🕨

(2) Select "METRIC" or "ENGLISH" by the or
 ♦ or
 ♦ wey and press the
 ■ wey.
 ■ Note: For using of Inch, please select "ENGLISH".




(3) "LCD POWER OFF": when setting time for extinguishing LCD. [To turn off LCD automatically]

Set the LCD off time (the setting range is from 0 to 30min)

If key operation is not performed, the backlight of the LCD (screen) goes off automatically and then the power of LCD will be OFF. If key operation is performed while the backlight is kept off, it comes on.

If 0 min. is selected for OFF time, the light is kept ON.



[Operation]

- (1) Press the ▲ or ♥ key on the BASIC SETUP screen and select "LCD POWER OFF".
 Press the ENT key, and you are ready to set the LCD off time.
- (2) Move the digit by the or key and enter numeric values by pressing the or key. After entry, press the key.

BASIC SETUP
, CLOCK
DATE DISPLAY
YYYY/MM/DD 🔻
SET DATE/TIME
2008/01/09 14:14
SYSTEM UNIT
LCD POWER OFF
0 min
1/2 🕨


(4) "DEFINITION OF PRINT KEY": when setting the PRINT key [To select printer and SD memory]

[Operation]

 Press the ▲ or ▼ key on the BASIC SETUP screen and select "DEFINITION OF PRINT KEY".
 Press the ENT key to open the DEFINITION OF PRINT KEY selection screen.

BASIC SETUP
DEFINITION OF PRINT KEY
SD MEMORY -
NORMAL
MEMORY INITIALIZE
◀ 2/2

(2) Select "PRINTER" or "SD MEMORY" by the ▲ or
 ♦ key and press the ENT key.



- \bigwedge caution -

When the SD MEMORY is selected, display screen capture can be produced and stored in the SD memory as BMP format.

When the printer is selected, print the screen display.

(5) MEASURE METHOD: when changing measurement method

NORMAL is the standard measurement method.


ANTI-DISTURBANCE MODE resists an external disturbance.

If the MODE is not available, change it to the ANTI-DISTURBANCE MODE.


The measurement system is automatically selected according to the kind of sensor or setting of outer diameter. If the ANTI-DISTURBANCE MODE is automatically selected from the beginning, there is no need to switch the method. For the MODE that has been automatically selected, change to the ANTI-DISTURBANCE MODE is possible.

[Operation]

(1) Press the ▲ or ♥ key on the BASIC SETUP screen and select "MEASURE METHOD".
 Press the ENT key, and the screen appears, prompting you to select measurement method.



 (2) Select "NORMAL" or "ANTI-DISTURBANCE MODE" by the or key and press the key.



The measurement method is initialized according to the kind of sensor or outer diameter setting at the power ON or just when the PROCESS SETTING screen is displayed on the SITE SETTING. After changing from NORMAL to ANTI-DISTURBANCE MODE, the unit will set the measurement method again when the power is turned OFF or the PROCESS SETTING screen is displayed.


\land CAUTION -

When the measurement method has been changed from NORMAL to ANTI-DISTURBANCE MODE, measurement values are subjected to change.

(6) MEMORY INITIALIZE: The setting parameters are initialized.

[Operation]

 Press the ▲ or ▼ key on the BASIC SETUP screen and select "MEMORY INITIALIZE".
 Press the ⊕ key, and you are ready to initialize the data.



(2) Select "INITIALIZE" by pressing the (a) or (v) key and press the (ENT) key.




NOTE) The following data will be retained.

- (1) The site that has been not selected in site memory
- (2) Clock
- (3) Analog output/ input calibration value
- (4) The contents of SD memory card
- (3) Select "To Execute" by pressing the ▲ or ♥ key and press the ENT key.

– vee Caution —

When the parameter is initialized, display language is set to English.


For changing display language, refer to "5.2 Turning on power and language preference".





10.3.2 "ANALOG INPUT/OUTPUT": when performing analog input/output and calibration

This function allows you to set the analog input/output and perform input/output calibration.



1 to 5V DC 1 point

 Select "ANALOG INPUT/OUTPUT" on the SYS-TEM screen.
 Press the ENT key to display the ANALOG INPUT/ OUTPUT screen.


SYSTEM
1:BASIC SETUP
2:ANALOG INPUT/OUTPUT
3:CALORIE MODE
ANALOG INPUT/OUTPUT
SETTING INPUT OUTPUT
ANALOG INPUT/OUTPUT
USED
INPUT CH1 DEFINITION
CURRENT(APPLICATION) -
INPUT CH2 DEFINITION
CURRENT(DIFFEREN TEMP.) -

(1) "SETTING": when using analog input/output.

[Operation]

 Press the ENT key on the BASIC SETUP screen and move the cursor to "ANALOG INPUT/OUTPUT". Press the ENT key, and the screen appears, prompting you to decide whether analog input/output is used or not.

(2) Select "USED" or "NOT USED" by the ▲ or ♥ key and press the (ENT) key.



ANALOG INPUT/OUTPUT	
ANALOG INPUT/OUTPUT]-
NOT USED	1
USED	
L	

(2) "SETTING": when setting the kind of analog input

Definition of Analog input1

NOT USED: Select this, when it is not used.

Current input (APPLICATION): Connect the external flow transmitter of 4 to 20mA DC.

Current input (FEEDING TEMP.): For using the Calorie mode, connect the feed-temperature 4 to 20mA DC.

When you set the definition of analog input2 to "CURRENT INPUT (DIFFEREN TEMP.)", "CURRENT INPUT (FEED-ING TEMP.)" becomes invalid.

Voltage input: Connect the external flow transmission of 1 to 5V DC.

Definition of Analog input2

NOT USED: select this, when you do not use.


Current input (APPLICATION): Connect the external flow transmitter of 4 to 20mA DC.

Current input (RETURN TEMP.): For using the Calorie mode, connect the return-temperature 4 to 20mA DC.


Current input (DIFFEREN TEMP.): For using the Calorie mode, connect the FEEDING TEMP. and the RETURN TEMP. of 4 to 20mA DC.

[Operation]


 Press the ENT key on the SETTING screen and the cursor moves to "ANALOG INPUT/OUTPUT". Select "INPUT CH1 DEFINITION" or "INPUT CH2 DEFINITION" by the ▲ or ▼ key and press the ENT key.



 (2) The screen to select analog input definition is displayed. Select the kind of input and press the (ENT) key.



INPUT CH1 DEFINITION



INPUT CH2 DEFINITION

(3) "Input CH1, CH2 Analog Input CALIBRATION": when adjusting zero and span for input signals [Please prepare a current generator]

Calibration procedure

1) 10.3.2(1) set the "ANALOG INPUT/OUTPUT" to the "USE"

2) 10.3.2(2) set the definition of "SETTING" input CH to "CURRENT INPUT".

[Operation]

Move the cursor to the "INPUT" on the SETTING screen by pressing the or key and display the INPUT screen.
 Press the (ENT) key, and the cursor moves to INPUT

CH1 or CH2. Select "CH1: INPUT PROOFREADING" by the \checkmark or \checkmark key and press the (ENT) key.


Select the kind of input you set on the "SETTING" screen by the (a) or (key and press the (ENT) key. The cursor moves to "ADJUST". Press the (ENT) key, and you are ready to adjust input signals.

(2) Input 4 mA from external and move the cursor to "4 mA" by the or key. Then press the key to adjust zero.

Follow the procedures described in next page of input calibration.

(3) Input 20 mA from external and move the cursor to "20 mA" by the or key. Then press the key to adjust span.

Follow the procedures described in next page of input calibration.



ANALOG INPUT/OUTPUT				
SETTING INPU	T CUTPUT			
CH1:INPUT PROOF	READING -			
CURRENT INPUT	ADJUST			
	UNADJUSTED			
VOLTAGE INPUT	ADJUST			
	UNADJUSTED			
CH2:INPLIT_PROOFREADING				
CURRENT INPUT				
CONNENT INPUT	UNADJUSTED			
	UNADOUSTED			

ANALOG INPUT/OUTPUT			
SETTING Y INPUT Y OUTPUT			
CH1:INPUT PROOFREADING -			
CURRENT INPUT ADJUST ADJUST			
VOLTAGE INPUT ADJUST UNADJUSTED			
CH2:INPUT PROOFREADING			
CURRENT INPUT			
UNADJUSTED			

Current Input Calibration procedure

ANALOG INPUT/OUTPUT SETTING INPUT OUTPUT CH1:INPUT PROOFREADING CURRENT INPUT ADJUST UNADJUSTED VOLTAGE INPUT ADJUST UNADJUSTED CH2:INPUT PROOFREADING CURRENT INPUT ADJUST UNADJUSTED	SETTI CH1: CURR	OG INPUT/OUTPUT ING INPUT OUTPUT INPUT PROOFREADING RENT INPUT ADJUST UNADJUSTED MA calibration EXECUTION CHARGE OF EFF CAMA from external.	ENT ENT ENT ENT ENT	G INPUT/OUTPUT NG INPUT OUTPUT NPUT PROOFREADING ENT INPUT ADJUST UNADJUSTED Calibration is being calibrated. Composed ED er calibration of 4mA
20mA calibratio	EADING ADJUST UNADJUSTED	ANALOG INPUT/OL SETTING INPUT CH1:INPUT PROOF CURRENT INPUT 20mA calibrati 20mA is being c	COUTPUT	ANALOG INPUT/OUTPUT SETTING INPUT OUTPUT CH1:INPUT PROOFREADING CURRENT INPUT ADJUST ADJUST VOLTAGE INPUT ADJUST UNADJUSTED CH2:INPUT PROOFREADING CURRENT INPUT ADJUST UNADJUSTED

Input 20mA from external.



End of calibration After calibration, the "End of Calibration" message appears under the end of calibration button.

- \land caution .

- Analog input has already been calibrated on the factory setting
- When you interrupt the calibration in the middle, the calibration value will be lost. If you interrupt the calibration, start from the beginning again.
- Calibrated analog input required for AI measurement.

(4) "Input CH1 Voltage Input CALIBRATION": when adjusting zero and span for input signals [Using a voltage generator]

Calibration procedure

- 1) 10.3.2(1) set the "ANALOG INPUT/OUTPUT" to the "USE"
- 2) 10.3.2(2) set the definition of "SETTING" input CH to "VOLTAGE INPUT".

[Operation]


Press the (ENT) key, and the cursor moves to INPUT CH1.

Select "INPUT CH1." by the or key and press the ENT) key.

Select the kind of input you set on the "SETTING" screen by the () or () key and press the (INT) key. The cursor moves to "ADJUST". Press the (INT) key, and you are ready to adjust input signals.

(2) Input 1V from external source and move the cursor to "1V" by the ▲ or ♥ key. Then press the ENT key to adjust zero.


Follow the procedures described in next page of input calibration.



ANALOG INPUT/OUTPUT		
SETTING INPU	T Y OUTPUT	
CH1:INPUT PROOF	READING	
CURRENT INPUT	ADJUST	
	ADJUST	
VOLTAGE INPUT		
	UNADJUSTED	
LCH2:INPUT PROOF	READING -	
CURRENT INPUT	ADJUST	
	UNADJUSTED	

(3) Input 5V from external source and move the cursor to "5V" by the or key. Then press the key to adjust span.

Follow the procedures described in next page of input calibration.



Voltage Input Calibration procedure

ANALOG INPUT/OUTPUT SETTING INPUT OUTPUT CH1:INPUT PROOFREADING CURRENT INPUT ADJUST VOLTAGE INPUT ADJUST UNADJUSTED CH2:INPUT PROOFREADING CURRENT INPUT ADJUST UNADJUSTED	SETTING INPUT OUTPUT CH1:INPUT PROOFREADING CURRENT INPUT ADJUST ADJUST IV calibration EXECUTION ANNOCOTED	VALOG INPUT/OUTPUT ETTING INPUT OUTPUT CH1:INPUT PROOFREADING CURRENT INPUT ADJUST ADJUST 1V calibration 1V is being calibrated. EXTRODUCTED Under calibration of 1V
ANALOG INPUT/OUTPUT SETTING INPUT OUTPUT CH1:INPUT PROOFREADING CURRENT INPUT ADJUST ADJUST SV calibration EXECUTION ONE DOCOTES Input 5V from external.	CH1: INPUT PROOFREAD ING CURRENT INPUT ADJUST	ANALOG INPUT/OUTPUT SETTING INPUT OUTPUT CH1:INPUT PROOFREADING CURRENT INPUT ADJUST ADJUST VOLTAGE INPUT ADJUST CH2:INPUT PROOFREADING CURRENT INPUT ADJUST UNADJUSTED End of calibration After calibration, the "End of

After calibration, the "End of Calibration" message appears under the end of calibration button.

- \wedge caution .

- Analog input has already been calibrated on the factory setting
- When you interrupt the calibration in the middle, the calibration value will be lost. If you interrupt the calibration, start from the beginning again.
- Calibrated analog input is required for AI measurement.

(5) AO CALIBRATION: when adjusting output circuit (prepare an ammeter)


Calibration procedure 10.3.2(1) set the "ANALOG INPUT/OUTPUT" to the "USE"

[Operation]

(1) Move the cursor to the "OUTPUT" on the SETTING screen by pressing the or key and display the OUTPUT screen.


Press the (ENT) key, and the cursor moves to 4 mA.

- (2) Select either 4 mA or 20 mA by the or , and press the ENT key.
 Adjust the output circuit so that outputs are adjusted to either 4 mA (0% output calibration) or 20 mA (100% output calibration) by pressing the or key.
- (3) Press the (ENT) key to set up.




10.3.3 "CALORIE MODE": when measuring consumed heat quantity


This function calculates the heat quantity received and sent with liquid (water) in cooling and heating.




(1) Select "CALORIE MODE" on the SYSTEM screen. Press the ENT key to display the CALORIE MODE screen.



(2) Make each setting on the CALORIE MODE screen. (For details, refer to the setting contents in the following page.)






Sets the returning temperature. When you select "ANALOG INPUT	CALORIE MODE RETURNING TEMPERATURE
CHANNEL2", current input of CH1 is set to the returning temperature. Set the 10.3.2(1) Input CH2 of clause	. ANALOG INPUT CHANNEL 2 TEMPERATURE SETTING
definition to "CURRENT INPUT (DIFFEREN TEMP.)" or "CUR- RENT INPUT (RETURN TEMP.)". When you select "TEMPERATURE	
SETTING", the entered temperature is set to returning temperature. Setting range : -20 to 120°C	

- Note1) To set the feed/return temperature to the fixed temperature (TEMPERATURE SETTING), make settings for feed/return temperature on the ANALOG INPUT CHANNEL1 and ANALOG IN-PUT CHANNEL2 screen.
- Note2) When the difference between the feeding temperature and the returning temperature is -0.5 to +0.5, thermal flow is zero.


10.4 Setting of range (setting screen for input/output range)

Set the measuring unit, range, output mode and error handling for analog input/output.


10.4.1 Setting the input range: When setting the range for the input current or input voltage. Setting range: 0.000 to ±9999999999




(1) Press the ▲ or ♥ key on the RANGE screen to select "INPUT RANGE".
 Press the ENT key to display the INPUT RANGE screen.



(2) Select "CH1" or "CH2" by the \bigcirc or \triangleright key and press the \bigcirc NT key.



(3) The cursor moves to "BASE SCALE". Press the ENT key, and you are ready to set the base scale. Move the digit by the ● or ● key and enter numeric values by pressing the ● or ● key. After entry, press the ENT key to set the base scale.




(4) Move the cursor to "FULL SCALE" by the or key, and set the full scale in the same manner as the base scale.





10.4.2 Setting the output range

(1) Press the ▲ or ♥ key on the RANGE screen and select "OUTPUT RANGE" from "OUTPUT".
 Press the ENT key, and the OUTPUT RANGE screen is displayed




(1) "RANGE": when setting kind of output range, range type, full scale value and output limit value.





Bi-directional range: Also output back-flow by 0 to 100%. When switching flow direction, Hysteresis will be 10% in full scale.

(1) Select "RANGE" on the OUTPUT RANGE screen and press the ENT key and the cursor moves to "KIND".





(2) Set the kind of output range (velocity, flow rate and thermal flow).

Press the (ENT) key, and the screen appears, enabling you to select the output range.

Select the kind of output range by the (\bullet) or (\bullet) key and press the (\bullet) key.

For the flow rate of the output range kind, set 10.3.3 of "Calorie mode" to "Used"





- (5) Set the full scale value for output range. Setting range: When the range kind is velocity or flow rate 0.000, ±0.300 to ±32.000m/s (Flow velocity conversion)
 When the range kind is thermal flow rate 0.000 to 999999999
 Select "FULL SCALE" by pressing the ▲ or ♥ key. Press the (ENT) key, and you are ready to set the full scale.
- (6) Move the digit by the or key and enter numeric values by pressing the or key. After entry, press the key to set the range. The full scale value will be set.
- (7) Make settings for output limit high/low (upper/lower limit for analog output).
 Setting limit: Output limit low -20 to 0% Output limit high 100 to 120%
 Select "OUTPUT LIMIT LOW" by the ▲ or ♥ key.
 Press the ENT key, and you are ready to set the output limit low.

OUTPUT	
RANGE	тионала
SINGL BI-DI	

OUTPUT RANG	E
RANGE	BURNOUT
KIND	FLOW RATE
RANGE TYPE	
FULL SCALE	SINGLE 🔻
	555.773020 m ³ /h
OUTPUT LIMIT	LOW
	-20 %
OUTPUT LIMIT	in an
	120 %

OUTPUT RANGE	
RANGE	BURNOUT
KIND RANGE TYPE FULL SCALE	FLOW RATE - SINGLE - 555.773020 m ³ /h
OUTPUT LIMIT	
	-20 %
OUTPUT LIMIT	HIGH 120 %

- (8) Move the digit by the or key and enter numeric values by pressing the or key. After entry, press the ENT key to set the range.
- (9) Select "OUTPUT LIMIT LOW" by pressing the ▲ or ▼ key.Set the output limit high in the same manner as the output limit low.

Set RANGE so that flow rate to be measured exceeds 1.2 times its maximum value. If measured value exceeds the set value, the status display on the measurement screen turns "E4: RANGE OVER".

Unless analog output is used, set the full scale setting at 0, and "E4: RANGE OVER" is not displayed.

(2) "BURNOUT": setting of analog output at error (Burnout)

When an error occurs, set a current output to force a set value. When resolving the cause, the current output is automatically restored. "PLIPNOLIT" means that the error ende shows E2 or E3

"BURNOUT" means that the error code shows E2 or E3.


(1) Select "BURNOUT" on the OUTPUT RANGE screen and press the ENT key, the cursor moves to "OUTPUT BURNOUT".

OUTPUT	RANGE		
RAN	GE)	BUR	NOUT
OUTPUT	BURNOUT		
		HOLD	▼
BURNOUT	TIMER		
			10 sec

(2) Set the action to be taken at the time of burn-out. Press the (ENT) key, and the BURNOUT screen appears.

OUTPUT	RANGE	
RAN	GE 🍸	BURNOUT
OUTPUT	BURNOUT	
BURNOUT	TIMER	HOLD 🔽
		10 sec

(3) Select any of the BURNOUT items by the ▲ or ♥ key and press the (ENT) key.



(5) Move the digit by the \bigcirc or \bigcirc key and enter numeric

values by pressing the (a) or (v) key. After entry, press the ENT key.

OUTPUT RANGE	
	NOUT
OUTPUT BURNOUT	
HOLDING	10DE 🔫
BURNOUT TIMER	
	10 sec

HOLD: Holds output indications before the occurrence of errors.
UPPER: 10.4.2(1) the setting of "Output limit high" is output.
LOWER: 10.4.2(1) the setting of "Output limit high" is output.
ZERO: Outputs (0%, 4 mA) at zero point

10.5 Use of printer function (PRINTER screen)


It allows you to print measured value as well as hard copy on an optional printer. On this page, setting for printing measured values and screen hard copy can be performed. For connecting the printer, refer to section "14 HOW TO USE PRINTER".

10.5.1 Selection of printing mode


Select any of the modes of "TEXT", "GRAPH", and "LIST" on the PRINTER screen by the

 ▲ or ♥ key.

Press the (ENT) key to switch the printing mode setting screen. For the meaning of each mode, refer to the example below.



10.5.2 Example of printing



10.5.3 PRINT OF TEXT

Up to 14 items available for printing are listed below:

- Flow rate (2 items)
- · Flow velocity
- Totalizer (2 items)
- Analog input (2 items)
- Thermal flow rate (7 items)

Only desired items out of 14 items are allowed to print. One or more items are selectable simultaneously.

 When the cursor is pointed to "KIND" on the PRINT OF TEXT screen, press the ENT key to select the item to be printed as text data.
 Press the (A) or (T) key to select the item to print and

Press the \bigcirc or \bigcirc key to select the item to print and press the ENT key.

To display the items on the second page, press the \bigcirc or \bigcirc key so that the page is switched.

After selection, return the cursor to "KIND" by the (ESC) key.

Press the (ENT) key to select the following mode of the timer.

- MANUAL
- QUICK TIME
- TIMER
- Then, set the printing cycle. Setting range: 1min. to 24hours
- (3) Move the cursor to "START" and press the ENT key to start printing.
 "START" switches to "STOP" indication.

Move the cursor to the "STOP" for interruption of printing, and press the (ENT) key, the printing will stop.



10.5.4 PRINTING OF GRAPH

Up to 10 items available for graph printing are enumerated below:

- Flow rate (2 items)
- + Flow rate total
 Flow rate total

- Flow velocity
- Analog input (2 items)
- + Thermal total
- Thermal flow rate (5 items)
- Thermal total

Only desired items out of 10 items are allowed to print. One or more items are selectable simultaneously.

When the cursor is pointed to "KIND" on the PRINT-ING OF GRAPH screen, press the ENT key to select the item for which graph is to be printed.
 Press the or key and press the ENT key.


After selecting the item, return the cursor to "KIND" by the (ESC) key.

(2) Move the cursor to "SCALE" by the or key.
Press the with the scale can be set.
After setting the maximum and minimum values of data, and press the with the cursor to "SCALE".

- (3) Move the cursor to "TIMER" by the or key.
 Press the key to select the following mode of the timer.
 - MANUAL
 - QUICK TIME
 - TIMER

Then, set the printing cycle.

(4) Move the cursor to "START" and press the key to start printing.



CYCLE

START

00:00:01

10.5.5 PRINT OF LIST

It allows you to print lists of site setting, range and system:


- Selects the kind of list.
 As for site setting, the currently selected setting will be printed.
- (2) Move the cursor to "START" and press the *ENT* key to start printing.

PRINT OF LIST	
LIST KIND	
□ SITE SETTING NAME >(default)	
□ RANGE □ SYSTEM	
START	

10.5.6 STATUS DISPLAY

It allows you to display the printer status and perform the printing test.

- Content of "STATUS DISPLAY"
 - 1) NORMAL
 - 2) DURING PRINTING
 - 3) ERROR
 - Show the contents of error display below
 - Printer is not connected
 - Printer is broken



10.6 Maintenance function (MAINTENANCE screen)

This function allows you to check the condition of this instrument.


10.6.1 Checking receiving status for transit time

(1) When an error is detected on measurement screen


 Move the cursor to "1:TRANSIT TIME" on the MAINTE screen and press the ENT key. The TRANSIT TIME/SIGNAL CHECK screen is displayed.



(2) Move the cursor to the status display field on the "TRANSIT TIME/SIGNAL CHECK" screen and press the (ENT) key.




For content of error, refer to "10.8 Contents of errors in status display"



(2) To check for ultrasonic receiving signal waveform;

(1) Move the cursor to "TRANSIT TIME" on the MAINTE screen and press the ENT key, and the TRANSIT TIME/SIGNAL CHECK screen is displayed.



- (2) Move the cursor to "SOURCE" on the TRANSIT TIME/RECEPT.WAVE screen and press the ENT key.

TR	ANSIT	TIME/SIGNAL	CHECK
S	AUCE		
	U:WAVE D:WAVE		
	U:FILT D:FILT		
	CALCUL		
:			ŀ

(4) When SOUDCE is selected SICNAL CHECK dis


Select the following waveform by the \triangle or \bigtriangledown key


(3) The SOURCE screen appears.


and press the (ENT) key.


• U: WAVE • D: WAVE

(4) When SOURCE is selected, SIGNAL CHECK display will be started.










Data



(5) To enlarge/contract waveform; By pressing (\blacktriangle) or (\blacktriangledown) key, move the cursor to "ZOOM" and press the (ENT) key to enlarge/contract waveform. To enlarge/contract the time axis (horizontal axis), press the \bigcirc or \bigcirc key. To enlarge/contract the data axis (vertical axis), press the \bigcirc or \bigcirc key.

Press the \triangle or \bigtriangledown key, move the cursor to

"SCROLL" and then press (ENT) key, SCROLL will be

For movement of time axis, press the \bigcirc or \bigcirc key.

(6) To move Time axis;

readied.

Zoom bar

(7) For adjusting the time axis migration; Point the cursor to "CURSOR" and press the (ENT) key to display the cursor. Press the \bigcirc or \bigcirc key to move the cursor to a receiving signal waveform-like point.

By pressing \bigstar or \bigtriangledown key, Point the cursor to

You are now ready to check measurement data.

TRANSIT TIME/MEAS. DATA screen.

"MEAS. DATA" and press the (ENT) key to display the

(8) To check measurement data;

Explanation of measurement data

Signal power

Displays the intensity of received signals.

The larger the value, the larger the intensity of received signals.

Normal measurement values fall in 35% or more.

For 0%, there is no received signal.

Ultrasonic waves may not be transmitted because of insufficient water volume or rust of piping.

• Trigger level

Displays the detection level of received waveform.

• Signal peek

Displays the peak value of received waveform.


Normal stable values fall within the range from 5528 to 6758.

If the value fluctuates significantly, objects that constitute barriers against ultrasonic wave transmission such as air bubbles or foreign matter may be contained in the fluid.

Stop the flow, and if the measurement is found to be normal, then there is a possibility that air bubbles are entrained.

• Fluid sound velocity


Displays the calculated value of the fluid sound velocity.



[Remark] Check to judge whether ultrasonic receiving signal waveform is normal or not

(1) Normal waveform

The receiving waveform is free of noise, normal measurement can be performed.



(2) Abnormal waveform

The receiving waveform is not covered within the range of the ultrasound waveform.

It is displayed as "E2: CALCULATION ERROR" or "E2: RECEIVED SIGNAL ERROR".


Check the pipe setting and sensor mounting dimensions.


When ultrasonic receiving signal waveform is weakened by the effect of rust in the pipe, abnormal waveform may result. Raise the transmission voltage and perform measurement. (See page 36).

(3) No received signal

The waveform is free of the received waveform, and this is the waveform to which the noise is expanded. The equipment cannot measure.

Ultrasonic waves may not be transmitted because of insufficient water volume or rust of piping.






10.6.2 Check for analog input/output

(1) Analog input

When the current input for CH1 and CH2 is 4-20mA or the voltage input is 1-5V, it is possible to check for the input status.

(1) Move the cursor to "CHECK" on the MAINTENANCE screen and press the ENT key to display the CHECK screen.



(2) Check for the current input and the voltage output on ANALOG INPUT of the CHECK screen.

Display unit

- Current input: mA
- Voltage input: V

CHECK	
ANALOG INPUT	ANALOG OUTPUT
URRENT INPUT	СНЕСК —
СН1	-0.005 mA
CH2	0.002 mA
VOLTAGE INPUT CH1	CHECK

(2) Analog output

It allows you to set the constant current output of analog signal.

When setting the simulating output (test mode), each output can be checked (LCD display, analog output). With the output at the actuated time as an initial value, the output changes up to the input value (simulated flow rate target value) in a selected tracking time and, at the input data, the analog output value becomes constant.

(1) Generate a fixed value output; use when checking the operation of a connected receiver and current output circuit of the main unit.

Setting range: -20 to 120%Move the cursor to ANALOG OUTPUT on the CHECK screen and press the \overline{ENT} key. The cursor moves to ANALOG OUTPUT, prompting you to set the constant current output value.

(2) When using the test mode to check for the measurement status, move the cursor pointed to ANALOG OUTPUT to TEST MODE and make the following settings.

"TEST MODE": USED/NOT USED

"INPUT DATA": Simulated flow rate target (percentage of maximum flow rate).

"TRACKING TIME": Time required to attain the simulated flow rate target.


Setting range: Input data: 0 to $\pm 120\%$


Tracking data: 0 to 900sec. * For setting TRACKING TIME, 0sec is set to the

damping (See 10.1.4(4)).

🕂 CAUTION -

- Be sure to return the setting to "NOT USED" after the test is completed. Otherwise, the output will be held at the input data value until power is turned off.
- If total function is in use, Test Mode will affect totalization.
- If you set the Thermal flow of "10.4.2(1) Type of Output range", test mode function will be disabled.
- When changing to the transit time difference on the maintenance screen or the flow velocity profile screen, the test mode will be cancelled.






CHECK
ANALOG INPUT ANALOG OUTPUT
CURRENT OUTPUT CHECK
CHECK 0 %
TEST MODE
INPUT DATA
0 % TRACKING TIME
0 sec

CHECK	
ANALOG INPUT	ANALOG OUTPUT
CURRENT OUTPUT	СНЕСК —
	0 %
TEST MODE	
INPUT DATA	NOT USED 🔻
INFUL DATA	0 %
TRACKING TIME	
	0 sec

10.6.3 SD memory card

It allows you to check for the following data in the SD memory.

- Logger data: Display of logger conditions and total data.
- Print screen: Display of data screen.
- Flow profile: Display of file name only.
- (1) Move the cursor to "SD MEMORY CARD" on the MAINTE screen and press the ENT key to display the SD MEMORY CARD screen.



(2) Press the ENT key on the SD MEMORY CARD screen and the CHECK screen appears.

SD	MEMORY CARD
(de	fault)
CH	ECK LOGGER DATA 💌
CA	PACITY 200.875 Mbyte
AV	AILABILITY 42.000 Mbyte
No	LOGGER DATA
1	AE_20080417_231000
2	A_20080216_144200
3	QUICK_20080205_133627
4	QUICK_20080216_132317
5	QUICK_20080216_132450
6	QUICK_20080216_143057
7	QUICK_20080404_102136
8	QUICK_20080404_111451 QUICK_20080404_125958
10	QUICK_20080404_125958 QUICK_20080414_150515
-10	W010K_20000414_130313


(3) Move the cursor to the data items to be checked
 (LOGGER DATA, PRINT SCREEN and FLOW
 PROFILE) by the or key and press the key.




(1) To check for logger data

(2) The contents of the logger data is displayed as text data.

To return to the selection screen, press the (sc) key.



SD	MEMORY	CARD/LOGGER	DATA
AE_2	20080417	7_231000	
S	TART TIM	1E	
		2008/04/17 2	3:10
S	TOP TIME		
		2008/04/18 09	9:10
C,	YCLE		
		00:00	0:10
D/	ΑΤΑ ΤΟΤΑ	۱L	
		:	3601



0	SD	MEMORY CARD
	CH	fault) ECK <u>FLOW PROFILE</u> PACITY 201.188 Mbyte AILABILITY 41.688 Mbyte
	No	FLOW PROFILE
	1	VEL_20071212_205402
	2	VEL_20080408_194850
	3	VEL_20080418_101227
	4	VEL_20080418_110214
	5	VEL_20080421_211403
	6	VEL_20080421_211423
	7	VEL_20080421_211542
	8	VEL_20080421_211552
	9	VEL_20080421_211617
	10	

(2) To check for print screen data

- When "PRINT SCREEN" is selected on the SD MEMORY CARD screen, the screen appears, prompting you to select the dump data. Move the cursor to the screen data file to be checked by the ▲ or ▼ key and press the ENT key.
- (2) The screen data is displayed. Turn back from data screen display, press the sc key.

(3) To check for flow profile data

 When you select "FLOW PROFILE DATA" on the SD memory card screen.
 File name list for "FLOW PROFILE DATA" is displayed.

(4) To delete logger data

(1) Select "LOGGER DATA" on the SD memory card screen.

The selection screen of logger data appears, move the cursor to the logger data which you want to delete by the \bigcirc or \bigcirc key.

(2) Move the cursor to the logger data you want to delete, press the or key. The message on the right side will be displayed.

Press the (ENT) key selecting "YES", the data will be deleted.

Note) The logger data can not be deleted under logging.

1.0	SD	MEMORY CARD
1	(de	fault)
	CH	ECK LOGGER DATA -
	CA	PACITY 201.031 Mbyte
	AV	AILABILITY 41.844 Mbyte
	No	LOGGER DATA
	-1	AE_20080417_231000
	5	A_20080216_144200
	3	QUICK_20080205_133627
	4	QUICK_20080216_132317
	5	QUICK_20080216_132450
	6	QUICK_20080216_143057
	7	QUICK_20080404_102136
	8	QUICK_20080404_111451
	9	QUICK_20080404_125958
	10	QUICK_20080414_150515
	_	

(default)
CHECK LOGGER DATA
CAPACITY 200.875 Mbyte
AVAILABILITY 42.000 Mbyte
No LOGGER DATA
r- ¹
Delete?
NO YES
9 401CK_20080404_125958
10 QUICK_20080414_150515

10.6.4 LCD check

The display unit uses 4.7 inch color graphic display (240×320 dots). This function checks pixels of the liquid crystal display by displaying 16 colors in the horizontal stripes.

There is a possibility that surface irregularity occurs in the brightness due to characteristics of liquid crystal display. You are kindly requested to understand it in advance.

MAINTENANCE
1:TRANSIT TIME
2:CHECK
3:SD MEMORY CARD
4:LCD CHECK
5:SOFTWARE

Press the (ESC) or (MENU) key for returning from the LCD check screen.




10.6.5 Software

Software version check and software update are permitted.

- Version
- Update

(1) In order to check the version

Move the cursor to [Software] in the maintenance screen and press the (ENT) key. Transition to the software screen appears, and the version number is displayed.



Example)	SOFTWARE	
	VER. NO. UPDAT ING	Ver. 1.00
	UPDAT ING	


(2) In order to update the software

Preparation

Prepare an SD memory card containing update files.


Create a folder by name "UPDATE" just beneath the root folder of the SD memory card. Save two update files provided from manufacturer just beneath the folder.





Press the (ESC) key on the software screen. A message appears.

(1) If update is not necessary, select "No" using \bigcirc or





(2) If update is necessary, select "Yes" using

or
keys, and then press the

lesc key
Update is executed.
Restart occurs automatically on termination of update.
The length of time required for update is about 30 seconds.
Check the version after restart.



A CAUTION -

- For implementation of update, supply power from an AC power adaptor in the state where the battery is fully charged.
- If power is turned off during update, unit will no longer function.
- Other than analog input and output calibration values are initialized upon implementation of update. Moreover, the displayed language changes to English. For changing the displayed language, see "5.2 Turning on the power and language preference".

10.7 Flow velocity distribution display function (future option)

It is possible to measure the flow velocity distribution in real time by the pulse doppler method and to display the flow state in the piping.

Use this function for judgment if the flow rate measuring position is appropriate, for diagnosis of flow, for research, testing and others.

This function is applicable to the following types.

Main unit type: Must be specified at time of purchase

(with flow velocity distribution display function)


Sensor type: Small Sensor (Bore diameter; φ40 to 200mm Fluid temperature; -40 to +100°C) Medium Sensor (Bore diameter; φ100 to 400mm Fluid temperature; -40 to +80°C) Large Sensor (Bore diameter; φ200 to 1000mm Fluid temperature; -40 to +80°C)


10.7.1 Installing Detector

(1) Processing of detector mounting surface

Remove rust, pitch, surface irregularity and others from the pipe surface, to which a sensor is to be mounted, by the frame length of the sensor to be mounted, using thinner, sandpaper and/or other appropriate means.

Note) If the piping outer circumference is wound with jute, remove the jute from the entire outer circumference in a length that is frame length (L) + 200 mm.







(2) Installation of detector

(1) Wrap the belt around the pipe.


Small/Medium Sensor




Adjusts the length of the wire rope according to the piping size, fixes the wire on the pipe.




(2) Fully screw up to the right side.




(3) Before mounting the sensor to the pipe, apply grease evenly over the sensor unit and the absorber unit that are to contact the pipe.



(4) Fasten the sensor with the belt checking the flow direction.




(5) After fastening the sensor to the pipe, screw to the left side, attach the sensor firmly to the pipe.




(3) 2-paths

Gauge paper may is necessary for this work. (Refer to "8.7. How to make gauge paper".)How to determine mounting position




(4) Installation of detector


(1) Wrap the belt around the pipe.




Adjusts the length of the wire rope according to the piping size, fixes the wire on the pipe.




(2) Fully screw up to the right side.




(3) Before mounting the sensor to the pipe, apply grease evenly over the sensor unit and the absorber unit that are to contact the pipe.



(4) Fasten the sensor with the belt checking the flow direction.



(5) After fastening the sensor to the pipe, screw to the left side, attach the sensor firmly to the pipe.



(5) Connect the detector and the converter

Connect the sensor unit and the converter unit with the signal cable. For 1 path, connect them on the upstream side.



For 2 paths, connect them on both side of the upstream and the downstream.



10.7.2 Operation

(1) Flow velocity profile display

(1) Measurement screen

Preparation


Set the following items on the process setting screen

- Pipe outer diameter (Page 27), Material (Page 28), Thickness (Page 29)
- Lining material (Page 30), Thickness (Page 31)
- Fluid kind (Page 32)
- Transmission voltage (Page 36)

Note) For metal pipes, raise the transmission voltage to 160Vp-p.

(2) Press MENU key to display "MENU" screen. Select flow velocity profile with the cursor key.

2008/01/06 18:50	💁 🕡 🔕 🕅	1
(default)		LDG
FLOW RATE	m³∕h	-
	0.00	0
VELOCITY	m/s	
	0.00	0
FLOW RATE(%)	%	
	0.	0
E2:NO RECEIVED	SIGNAL	



(3) Press the (ENT) key twice, flow velocity profile screen will display.


FLOW PROFILE	PROF	
1:PROFILE	X 2- 84	4∕aiv
	SAUCE DAMP I CURSC	NG IR

PROFILE
E3:SUCCESS RATE
X:2.844/div Y:0.000/div
SAUCE <u>SENSOR-U</u> DAMPING 5 sec CURSOR
MEAS. DATA 📖 DETAILS

[flow velocity profile screen]

(2) How to observe flow velocity distribution screen

Typical flow velocity distribution measured using two sensors is shown below. Displays the radius of flow velocity profile by a single sensor.



 \triangle Display of flow velocity distribution begins upon selection of a source.

[Dumping] The flow velocity distribution is displayed as averaged.

Instantaneous data is displayed, if 0 display is set.

[Cursor] Move the cursor using (\bullet) , (\bullet) keys, and check the fluid velocity data.

Case where the measuring range is set as radius F

Flow velocity distribution 1: Distribution in the radius in case a sensor is connected to the upstream side connector (Sensor U)

Flow velocity distribution 2: Distribution in the radius in case a sensor is connected to the downstream side connector (Sensor D)

Case where the measuring range is set as radius N

Flow velocity distribution 1: Distribution in the radius in case a sensor is connected to the downstream side connector (Sensor D)

Flow velocity distribution 2: Distribution in the radius in case a sensor is connected to the upstream side connector (Sensor U)

Case where the measuring range is set as diameter

Distribution is displayed by diameter in areas of Flow velocity distribution 1 and Flow velocity distribution 2. (Sensor U, Sensor D or Sensor U/D)

Note) Measurement is normally taken in radius F.


(3) Detail setup


Set measuring conditions. Point the cursor to "DETAILS" by pressing (A), (V) key, and then press the (ENT) key.

PROFILE
E3:SUCCESS RATE
X:2-844/div Y:0-000/div
0.000 m/s
SAUCE SENSOR-U 💌
DAMPING 5 sec
CURSOR
MEAS. DATA 📖 DETAILS

(1) Sensor type

Point the cursor to "SENSOR TYPE" by using the (A), (key and press the (ENT) key. Select the type of sensors to be used.





Set connection between the sensor and conversion unit's connector.

Use the upstream side, normally in case one measuring line. (Sensor U)

In case of two measuring lines, use both of upstream side and downstream side. (Sensor U/D)

Make selection corresponding to the connection.

(3) Display selection

Point the cursor to "KIND" by using the (), () key and press the (

Either fluid velocity or flow rate is displayed together with flow velocity distribution.

Select the item to be displayed.

(4) Fluid temperature

Point the cursor to "FLUID TEMPERATURE" by using the (a), (v) key and press the (ENT) key. Input the fluid temperature.

The status for numerical value input is produced

when the (ENT) key is pressed.

Move the cursor to the point to change the numerical value, and change the numerical value using , keys.

Finalize the numerical value by pressing the (ENT) key.


(5) Measuring range


Point the cursor to "MEAS. RANGE" by using the $(\begin{subarray}{c} \bullet \end{subarray}, \begin{subarray}{c} \bullet \end{subarray}$ key and press the (ENT) key.

Select the range of flow velocity distribution to be measured.

Radius F: Measurement is taken on the radius side

opposite to the sensor. (Normally used.)






Radius N: Measurement is taken on the radius side adjacent the mounted sensor.




Diameter: Measurement is taken across the entire diameter.



(6) Setup of judgment value

Selects a page by using \bigcirc , \bigcirc key.

Set values for judgment of whether flow velocity distribution measurement is normal or abnormal. Success rate error arises, if measured values are less than judgment values. (Normally not used.)




FLOW PROFILE/DETAILS		
LINE 1-D POWER		
4.00 ×104 DEVIATION 0.50		
SUCCESS RATIO 70.00 %		
4 3/3		

(4) Measured data

Measured data is displayed.

Select measured data by the cursor key, and then press the (ENT) key.



Data of the present measuring conditions is displayed.

Power: Displays the intensity of the incoming signal.

Deviation: Displays the standard deviation of the Doppler shift.

Success rate: Displays the success rate of power and deviation.

MAX range: Displays the maximum measurable flow rate.

Analyzer measurable range can be changed by pipe usage or the sensor to be used in the Pulse Doppler method.

When stainless steel is selected as pipe material, nominal wall thickness is Sch20s, and the fluid is water, the following chart displays the measurable range in above condition.

<maximum flow="" measurable="" velocity=""> Unit: m/s</maximum>			<maximu< th=""></maximu<>	
Diameter	SMALL	MEDIUM	LARGE	SMALL
40A	6.56			3
50A	6.52			5
65A	5.31			7
80A	4.65			8
90A	4.12			10
100A	3.69	7.25		11
125A	3.08	6.08		14
150A	2.63	5.20		17
200A	2.04	4.05	7.77	23
250A		3.30	6.38	
300A		2.78	5.41	
350A		2.51	4.90	
400A		2.20	4.31	
450A			3.80	
500A			3.48	
550A			3.17	
600A			2.91	
650A			2.71	
700A			2.52	
750A			2.35	
800A			2.21	
850A			2.08	
900A			1.97	
1000A			1.77	

		Unit: m³/h		
	SMALL	MEDIUM	LARGE	
1	33.6			
	52.7			
	72.1			
	86.5			
	102			
	118	231		
	147	289		
	179	354		
	239	474	908	
		604	1168	
		735	1428	
		820	1598	
		951	1858	
			2118	
			2358	
			2618	
			2879	
			3096	
			3357	
			3618	

<Maximum measurable flow rate>

10.8 Contents of errors in status display


Use this page for checking the status of this equipment.

The present status is displayed in the measurement screen, propagation time difference receiving waveform screen, and flow velocity profile screen.

If any error was found, take actions in accordance with countermeasures against display contents and "12. ERROR AND REMEDY".


10.8.1 How to check status display

- (1) For checking an error in the measurement screen Move the cursor to the status display and then press the (ENT) key.



(3) The troubleshooting screen appears.


 $[\blacktriangleleft]$ and $[\blacktriangleright]$ are displayed, if the troubleshooting screen is of multiple pages. Change the page using , keys.



10.8.2 Action on error

(1) Error code: E1

Display the instrument abnormality.



(2) Error code: E2

Display the flow rate abnormality.

(1) E2: Windows scan



(3) Error code: E3

Display the flow velocity profile measurement.

- (1) E3: Measurement range error
 E3: MEASURE, RANGE ERR.
 1. DETAIL Setting is out of a measurement range. Measurement Impossible.
 2. CHECK AND MEASURE -Check if the parameters in site setting are OK. Pipe size(inner diameter):40mm to 1000mm -Check if the sensor type is correctly selected. -Turn the power off and on!

	E3:FREQENCY ERROR
e em- oc-	In case of no recovery after above measures, th- ere is not sufficient vo- lume of the particle ref- lectors in the fuluid. (Measurement impossible.)
s	
/ре	
	4

(3) E3: Success rate E3:SUCCESS RATE

1. DETAIL Measurement impossible due to too small volume of particle reflectors in fluid.
2. CHECK AND MEASURE -Check if the parameters in site setting are OK. -Check if the sensor type is correctly selected. -Try to reduce the succe- ss rate value.

(4) Error code: E4

Display the analog input/output error.

(1) E4: Range over

8
E4:RANGE OVER
1.DETAIL Output signal is out of the adjusta⊾le range.
2.CHECK AND MEASURE -Check and re-set the me- asuring range.
In case no need of output signal, set "OFF" for the parameter setting of Analog Input/Output func- tion.

(2) E4: Analog inout error			
	E4:ANALOG INPUT ERROR		
	1.DETAIL Analog input is аьпогт- аl.		
	2. CHECK AND MEASURE -Check the cable connect- ion. -Check the input signal. -Perform re-calibration of analog input. -Turn the power off and on!		

	E4:ANALOG INPUT ERROR
	In case of no recovery after above measures, co- ntact the nearlest Fuis sales office/aistributor. In case no need of Analog input signal, set "OFF" for the parameter setting of Analog Input/Output function.
ļ	4

(5) Error code: E5

Display the analog printer error.

 (1) E6: Printer fail
 E6: PRINTER FAIL

 DETAIL
 Printer Error. Cannot start printing.
 CHECK AND MEASURE
 -Check if the roll paper is correctly set.
 -Check whether paper is jammed or not!
 -Check whether paper is is correctly connected to the converter unit.
 -Turn the power switches of converter and printer unit off and on!

E6:	PRINTER FAIL
ver	case there is no reco- y after above measure- contact the nearlest sales office/distri-
ьut	
4	

(1) Cleaning of converter and detector

Wipe off contamination, dust, etc. from the keyboard and main frame of the converter unit occasionally with soft cloth or the like. If contaminants cannot be removed by wiping with dry cloth, moisten cloth with water, wring it adequately and wipe again.

Before accommodating the converter in the carrying case after use, wipe off grease completely. Note) Do not use volatile agents such as benzene and paint thinner for cleaning.

(2) When instrument unused

Put the instrument in the furnished carrying case and store it at a place which meets the following conditions.

- Not exposed to direct sunlight, rain, etc.
- Free from extremely high temperature and humidity (away from a heater) Storage temperature: -10 to 45°C
- Absence of excessive dust and other contaminants.

(3) Replacement of clock backup battery

In normal usage, the battery has a service life of about 10 years. When the battery has reached the end of its service life, the clock will be cleared. For replacement, contact manufacturer.

(4) Replacement of LCD

LCD has a lifetime of 5 years or longer when used continuously. When display becomes difficult to be read or the backlight does not come on, the LCD should be replaced with a new one. For replacement, contact the manufacturer.

(5) Replacement of built-in battery

If it cannot be charged, it is an indication that the battery life is terminated and it needs to be replaced.

For replacement, be sure to use the battery specified by Manufacturer.

(6) Replacement of printer roll-paper

When roll-paper is used for panel copy (hard copy), up to about 777 panels can be printed. When a red band appears on the roll-paper, it is an indication that little paper is left for printing. Replace with new one (manufacturer: SEIKO I SUPPLY Co. Ltd., Japan, type: LP-251L). (7) Reserved for future use

If an error occurs, refer to Table below.

12.1 Error in LCD Display

Status	Cause	Remedy
No display appears.	 Power supply is not turned on. Voltage is low. Fuse has blown. LCD is abnormal. Connection of DC power supply is reverse in polarity. 	⇒ See section 11 (4) "Replacement of LCD"
Irrational display	• Hardware error	
Display is not clear.	 Ambient temperature is high (50°C or higher) LCD has reached the end of its service life. 	⇒ Lower the temperature. ⇒ Replace the LCD.
Entire display is blackish.		⇒ See section 11 (4) "Replacement of LCD" ⇒ Lower the temperature.

12.2 Error of key

No response is made to key input.	• Hardware error
Any particular key does not function or functions in a wrong way.	

State	Cause		Remedy
Indication of measured value is negative (-).	• Connection between the main unit and sensors (upstream sensor and downstream sensor) is reverse.	⇒	Connect correctly.
	• Fluid is actually flowing in the (-) direction.		
Measured value fluctuated widely though flow rate is constant.	• Straight pipe portion is inadequate.	₽	Shift measurement location to the site where 10D and 5D can be secured on the upstream and downstream sides.
	• A flow disturbing factor such as pump or valve is provided in the vicinity.	⇔	Mount the instrument with a clearance of 30D or more.
	• Pulsation is occurring actually.	₽	Extend response time through damping setting.
Measured value remains the same	• Measured value is held because ultras wave cannot be propagated into a pip		
though flow rate is changing.	1. Incomplete installation		
uning ing i	 Piping specifications are wrong. Sensor is mounted at the welded part. Sensor mounting dimension is wrong. Grease application at sensor mounting is incomplete. Sensor connector is not connected completely. Pipe surface is contaminated. 	Ŷ	After check, separate the sensor once. Apply the grease again and remount the sensor with a slight shift.
	2. Problem on pipe or fluid		
	 When V method is used, it should be changed to Z method. When sensor extension cable is used, it should be avoided. If error persists, check and elimi- nate the true cause as instructed below. 		
	© Fluid is not filled.	⇔	Find the location on the same pipe line, where fluid is filled up and move the sensors to that location. Mount the sensors at the lowest location on pipe line.

12.3 Error in measured value

State	Cause		Remedy
	In case measurement is normal with water flow stopped, entrance of air bubbles is the cause of this error. Image: Comparison of the cause of	ſ	 Eliminate entrance of air bubbles. Raise the level of pump well. Confirm the shaft seal of pump. Retighten the flange of nega- tive pressure piping. Prevent fluid from rushing into pump well. Move the sensor to the loca- tion where air bubbles have not entered. To the inlet side of pump To the upstream side of valve
	└ sewage and return sludge. └		 Change the sensor mounting method from V to Z. Move the sensor to the location on the same line, where the outer diameter of pipe is smaller. Move to a different place or different pipe. Raise the voltage for transmission (refer to p.21).
	 ○ Lining is peeled. □ There is a gap between lining and piping. 		Try measurement with the optional large size sensor. ⇒ Contact Manufacturer.
	Sensor is mounted at a bent pipe or tapered pipe.	⇒	Mount to a straight pipe.
	 3. Influence by external noise There is a radio broadcasting station in the vicinity. Measurement has been conducted near heavy traffic. 	₽	• Minimize the cable between main unit and sensors.
	 Sensor mounting is incomplete. Mounting dimension is improper. Sensor is not in contact with pipe. 	♪	Mount the sensors in parallel with the pipe following the cor- rect mounting dimension. Bring the sensor in close con- tact with the pipe.
	4. Hardware error	⇒	Contact Manufacturer.

State	Cause		Remedy
Measured value is not zero though water flow has stopped.	• Water is subjected to convection in a pipe.	₽	Normal
	• Zero adjustment has been per- formed.	⇔	• Perform zero adjustment again after making sure water flow has stopped completely.
	• When water flow stops, pipe is not filled up with water or becomes empty.	⇔	The measured value, just when ultrasonic wave cannot be propagated, is held. ➡ Normal
Measured value has an error.	• Input piping specifications are dif- ferent from actual ones.	⇔	• A difference of 1% in inner diameter causes an error of about 3%.
	• Because of an old pipe, scale has stuck.	⇔	Input specifications correctly.Input scale as lining.
	 The length of straight pipe portion is inadequate. 10D and 5D are required at least on the upstream and downstream 	⇔	Select a different location of sensor mounting (move the up- stream side of a flow disturbing element).
	sides. Flow disturbing element should not be present within 30D on upstream side. Pump, valve, flow joining pipe or the like is unallowable.		• Mount the sensor at differ- ent angles with respect to the cross section of pipe to fine the location where mean value is obtainable. The mount the sensor at that location.
	• Pipe is not filled with water or mud and sand have precipitated.	⇔	Precipitation is more when the cross section of pipe has a smaller area. Shift the sensor to the vertical portion of pipe.
Flow velocity profile is not available.	No reflector in the fluid or weak reflection.	⇔	Measure in a place subject to reflector.
	© Low flow velocity.	⇒	Increase flow velocity.

12.4 Error in analog output

State	Cause		Remedy
Output remains at 4mA though indication value is other than 0.	Full scale range setting has not been made.	♪	Set the full scale. Otherwise, output remains at 4mA.
	◎ Cable is broken.	⇒	Repair
Output is 0mA.	◎ The setting of analog output is set as "NOT USED".	⇒	Change to "USE".
Output is not 4mA when indication value is 0.	The zero point of analog output is not adjusted properly.	⇔	Calibrate analog output.
Output rises beyond 20mA.	 Indication value is larger than analog span value. Span is deviated. 	⇔	Overshoot Set analog span again. Calibrate analog output.
Analog output remains the same despite change in indication value.	\bigcirc Output load is larger than 600 Ω .	₽	Permissible load is 600Ω . Reduce the load to less than 600Ω .
Indication value does not match analog output.	• Zero point and span of analog output are deviated.	₽	Calibrate analog output.
Output remains the same even after calibration of analog output.	• Hardware error	⇔	Contact Manufacturer.

13. EXTERNAL COMMUNICATION SPECIFICATION

(1) General specification

Item	Specification
Transmission scheme	Half duplex
Synchronization scheme	Asynchronous
Transmission rate	500kBPS
Parity	Odd parity
Start/stop bit	1 bit
Data length	8 bits
Station	0, fixed
Number of connectable units	1 unit
Transmission code	Hexadecimal value (MODBUS RTU mode)
Error detection	CRC-16
Echo back	None
Flow control	Xon/off

(2) Interface specification

Electrical specification: Conforms to USB standard. Cable length: 3 m or less Conforming cable: Mini USB cable Connection scheme: 1:1 connection

Support software

Loader software for PC is provided as standard.

- Main function: To display and change main unit parameters (site setup), and to acquire measured data.
 - It is capable of importing instantaneous flow rate, instantaneous fluid velocity, integrated value, error information, wave receiving level and others.

14.1 How to connect printer


- (1) Turn off the power supply of main unit.
- (2) Remove the rubber guards.



(3) Detach the top cover of main unit.



(4) Attach the printer.Connect the printer cord.



(5) Install the printer with 2 screws.




- (6) Install the rubber guardsNote) Install it so that the groove of the rubber guards may fit tightly on the edges of the main unit.
- (7) Turn ON the power supply of the main unit.

14.2 How to load printer roll sheet

(1) Open the cover and load a roll sheet



(2) Insert the edge of roll paper into the head assembly.Cut the edge of the recording paper so that central part of it can be inserted first.



Insert the paper straight to the paper insertion section.



(3) For feed paper, use FEED key of the main unit.



AUTION -

Don't pull the sheet opposite the FEED direction, or printer damage may result.

15. REPLACEMENT OF BUILT-IN BATTERY

- (1) Turn off the power supply of main unit.
- (2) Remove the rubber guard.

(3) Locate 4 screws at the corners of the back cover diagram label. Remove the 4 screws and cover as shown.



(4) Remove the battery and replace it with the appropriate service part.Note) Install a combination of the main unit side terminal and the battery side terminal.



- 🕂 CAUTION ———

- Do not give the equipment a shock
- Do not disassemble or modify the equipment
- Do not use the equipment with the built-in battery removed.

16.1 Piping data

(1) Stainless steel pipe for pipe arrangement(JIS G3459-1997)

Norr	ainal			Thickness					
diam		Outer	Schedule						
ulan	leter	diameter	5S	10S	20S	40	80	120	160
•	В	mm	Thickness						
A	В		mm						
10	1/8	17.3	1.2	1.65	2.0	2.3	3.2	_	-
15	1/2	21.7	1.65	2.1	2.5	2.8	3.7	-	4.7
20	3/4	27.2	1.65	2.1	2.5	2.9	3.9	-	5.5
25	1	34.0	1.65	2.8	3.0	3.4	4.5	-	6.4
32	1 1/4	42.7	1.65	2.8	3.0	3.6	4.9	-	6.4
40	1 1/2	48.6	1.65	2.8	3.0	3.7	5.1	-	7.1
50	2	60.5	1.65	2.8	3.5	3.9	5.5	-	8.7
65	2 1/2	76.3	2.1	3.0	3.5	5.2	7.0	_	9.5
80	3	89.1	2.1	3.0	4.0	5.5	7.6	_	11.1
90	3 1/2	101.6	2.1	3.0	4.0	5.7	8.1	_	12.7
100	4	114.3	2.1	3.0	4.0	6.0	8.6	11.1	13.5
125	5	139.8	2.8	3.4	5.0	6.6	9.5	12.7	15.9
150	6	165.2	2.8	3.4	5.0	7.1	11.0	14.3	18.2
200	8	216.3	2.8	4.0	6.5	8.2	12.7	18.2	23.0
250	10	267.4	3.4	4.0	6.5	9.3	15.1	21.4	28.6
300	12	318.5	4.0	4.5	6.5	10.3	17.4	25.4	33.3
350	14	355.6	-	-	-	11.1	19.0	27.8	35.7
400	16	406.4	-	-	-	12.7	21.4	30.9	40.5
450	18	457.2	_		-	14.3	23.8	34.9	45.2
500	20	508.0	_	-	-	15.1	26.2	38.1	50.0
550	22	558.8	-	-	-	15.9	28.6	41.3	54.0
600	24	609.6	_		_	17.5	34.0	46.0	59.5
650	26	660.4				18.9	34.0	49.1	64.2

(2) Polyethylene pipe for city water (JIS K6762-2004)

Nominal	Outer	1st type (Soft pipe)		2nd type (Hard pipe)
diameter	diameter	Thickness	Weight	Thickness	Weight
(mm)	(mm)	(mm)	(kg/m)	(mm)	(kg/m)
13	21.5	3.5	0.184	2.5	0.143
20	27.0	4.0	0.269	3.0	0.217
25	34.0	5.0	0.423	3.5	0.322
30	42.0	5.5	0.595	4.0	0.458
40	48.0	6.5	0.788	4.5	0.590
50	60.0	8.0	1.210	5.0	0.829

(3) Galvanized steel pipe for city water SGPW (JIS G3442-2004)

How to	call pipe	Outer diameter	Thickness
(A)	(B)	(mm)	(mm)
15	1/2	21.7	2.8
20	3/4	27.2	2.8
25	1	34.0	3.2
32	1 1/4	42.7	3.5
40	1 1/2	48.6	3.5
50	2	60.5	3.8
65	2 1/2	76.3	4.2
80	3	89.1	4.2
90	3 1/2	101.6	4.2
100	4	114.3	4.5
125	5	139.8	4.5
150	6	165.2	5.0
200	8	216.3	5.8
250	10	267.4	6.6
300	12	318.5	6.9

	1st	type	2nd	type	3rd	type	4th	type
Nominal	Thickness	Outer	Thickness	Outer	Thickness	Outer	Thickness	Outer
diameter	of	diameter of						
(mm)	connected	connected	connected	connected	connected	connected	connected	connected
(11111)	part	part	part	part	part	part	part	part
	(mm)	(mm)	(mm)	(mm)	(mm)	(mm)	(mm)	(mm)
50	10	70	-	-	-	-	-	-
75	10	95	-	-	-	-	-	-
100	12	124	10	120	9	118	-	-
125	14	153	11	147	9.5	144	-	-
150	16	182	12	174	10	170	-	-
200	21	242	15	230	13	226	11	222
250	23	296	19	288	15.5	281	12	274
300	26	352	22	344	18	336	14	328
350	30	410	25	400	20.5	391	16	382
400	35	470	29	458	23	446	18	436
450	39	528	32	514	26	502	20	490
500	43	586	35	570	28.5	557	22	544
600	52	704	42	684	34	668	26	652
700	-	-	49	798	39	778	30	760
800	-	-	56	912	44	888	34	868
900	-	-	-	-	49	998	38	976
1000	-	-	-	-	54	1108	42	1084
1100	-	-	-	-	59	1218	46	1192
1200	-	-	-	-	65	1330	50	1300
1300	-	-	-	-	73	1496	57	1464
1500	-	-	-	-	81	1662	63	1626

(4) Asbestos cement pipe for city water (JIS A5301-1971)

(5) Polyethlene pipe for general use(JIS K6761-1998)

	Outer	1st type	2nd type
Nominal	diameter	(Soft pipe)	(Hard pipe)
diameter	(mm)	Thickness	Thickness
	((((((((((((((((((((((((((((((((((((((((mm)	(mm)
13	21.5	2.7	2.4
20	27.0	3.0	2.4
25	34.0	3.0	2.6
30	42.0	3.5	2.8
40	48.0	3.5	3.0
50	60.0	4.0	3.5
65	76.0	5.0	4.0
75	89.0	5.5	5.0
100	114	6.0	5.5
125	140	6.5	6.5
150	165	7.0	7.0
200	216	-	8.0
250	267	-	9.0
300	318	-	10.0

(6) Hi vinyl chloride pipe (city water pipe size)

Nominal	Outer	Pipe
diameter	diameter	thickness
13	18.0	2.5
20	26.0	3.0
25	32.0	3.5
30	38.0	3.5
40	48.0	4.0
50	60.0	4.5
75	89.0	5.8
100	114.0	7.0
125	140.0	7.5
150	165.0	8.5

(7) Hi vinyl chloride pipe (conduit size)

Nominal diameter of pipe	Outer diameter	Pipe thickness
28	34.0	3.0
35	42.0	3.5
41	48.0	3.5
52	60.0	4.0
65	76.0	4.5
78	89.0	5.5

(8) Vertical type cast iron pipe (JIS G5521)

	Pipe th	ickness	Actual
Nominal			outer
diameter	Normal	Low	diameter
D	pressure	pressure	D1
	pipe	pipe	
75	9.0	-	93.0
100	9.0	-	118.0
150	9.5	9.0	169.0
200	10.0	9.4	220.0
250	10.8	9.8	271.6
300	11.4	10.2	322.8
350	12.0	10.6	374.0
400	12.8	11.0	425.6
450	13.4	11.5	476.8
500	14.0	12.0	528.0
600	15.4	13.0	630.8
700	16.5	13.8	733.0
800	18.0	14.8	836.0
900	19.5	15.5	939.0
1000	22.0	-	1041.0
1100	23.5	-	1144.0
1200	25.0	-	1246.0
1350	27.5	-	1400.0
1500	30.0	-	1554.0

(9)	Hard vinyl	chloride	pipe ((JIS	K6741-2004)
-----	------------	----------	--------	------	-------------

	V	Έ	V	U
Туре				
	Outer	Thickness	Outer	Thickness
Nominal	diameter		diameter	
(mm)				
13	18	2.2	-	-
16	22	2.7	-	-
20	26	2.7	-	-
25	32	3.1	-	-
30	38	3.1	-	-
40	48	3.6	48	1.8
50	60	4.1	60	1.8
65	76	4.1	76	2.2
75	89	5.5	89	2.7
100	114	6.6	114	3.1
125	140	7.0	140	4.1
150	165	8.9	165	5.1
200	216	10.3	216	6.5
250	267	12.7	267	7.8
300	318	15.1	318	9.2
350	-	-	370	10.5
400	-	-	420	11.8
450	-	-	470	13.2
500	-		520	14.6
600	-		630	17.8
700	-		732	21.0
800	_	_	_	_

(11) Coated steel pipe for city water PTPW (JIS G3443-1968)

Nominal diameter (A)	Outer diameter (mm)	Thickness (mm)
80	89.1	4.2
100	114.3	4.5
125	139.8	4.5
150	165.2	5.0
200	216.3	5.8
250	267.4	6.6
300	318.5	6.9
350	355.6	6.0
400	406.4	6.0
450	457.2	6.0
500	508.0	6.0
600	609.6	6.0
700	711.2	6.0
800	812.8	7.1
900	914.4	7.9
1000	1016.0	8.7
1100	1117.6	10.3
1200	1219.2	11.1
1350	1371.6	11.9
1500	1524.0	12.7

(10) Carbon steel pipe for pipe arrangement (JIS G3452-2004)

How to	call pipe	Outer	Thickness
(A)	(B)	diameter (mm)	(mm)
15	1/2	21.7	2.8
20	3/4	27.2	2.8
25	1	34.0	3.2
32	1 1/4	42.7	3.5
40	1 1/2	48.6	3.5
50	2	60.5	3.8
65	2 1/2	76.3	4.2
80	3	89.1	4.2
90	3 1/2	101.6	4.2
100	4	114.3	4.5
125	5	139.8	4.5
150	6	165.2	5.0
175	7	190.7	5.3
200	8	216.3	5.8
225	9	241.8	6.2
250	10	267.4	6.6
300	12	318.5	6.9
350	14	355.6	7.9
400	16	406.4	7.9
450	18	457.2	7.9
500	20	508.0	7.9

			Symbol	for type			Symbol	for type	
Manainal	Outor			STV	V 41			STW	/ 400
Nominal	Outer	STW 30	STW 38	Nominal	thickness	STW 290	STW 370	Nominal	thickness
diameter (A)	diameter (mm)			A	В			A	В
(A)	(((((((((((((((((((((((((((((((((((((((Thickness							
		(mm)							
80	89.1	4.2	4.5		_	4.2	4.5	_	_
100	114.3	4.5	4.9	-	-	4.5	4.9	-	_
125	139.8	4.5	5.1	-	-	4.5	5.1	-	_
150	165.2	5.0	5.5	-	-	5.0	5.5	-	-
200	216.3	5.8	6.4	-	-	5.8	6.4	-	_
250	267.4	6.6	6.4	-	-	6.6	6.4	-	_
300	318.5	6.9	6.4	-	-	6.9	6.4	-	_
350	355.6	-	-	6.0	-	-	-	6.0	_
400	406.4	-	-	6.0	-	-	-	6.0	-
450	457.2	-	-	6.0	-	-	-	6.0	-
500	508.0	-	-	6.0	-	-	-	6.0	-
600	609.6	_	-	6.0	-	-	-	6.0	-
700	711.2	_	-	7.0	6.0	-	-	7.0	6.0
800	812.8	-	-	8.0	7.0	-	-	8.0	7.0
900	914.4	-	-	8.0	7.0	-	-	8.0	7.0
1000	1016.0	-	-	9.0	8.0	-	-	9.0	8.0
1100	1117.6	-	_	10.0	8.0	-	-	10.0	8.0
1200	1219.2	-	-	11.0	9.0	-	-	11.0	9.0
1350	1371.6	-	_	12.0	10.0	-	-	12.0	10.0
1500	1524.0	-	_	14.0	11.0	-	_	14.0	11.0
1600	1625.6	-	_	15.0	12.0	-	_	15.0	12.0
1650	1676.4	-	_	15.0	12.0	-	_	15.0	12.0
1800	1828.8	-	_	16.0	13.0	-	_	16.0	13.0
1900	1930.4	-	_	17.0	14.0	-	_	17.0	14.0
2000	2032.0	-	_	18.0	15.0	-	-	18.0	15.0
2100	2133.6	-	_	19.0	16.0	-	-	19.0	16.0
2200	2235.2	-	_	20.0	16.0	-	-	20.0	16.0
2300	2336.8	-	-	21.0	17.0		-	21.0	17.0
2400	2438.4	-	-	22.0	18.0	-	-	22.0	18.0
2500	2540.0	-	-	23.0	18.0	-	-	23.0	18.0
2600	2641.6	-	-	24.0	19.0	-	-	24.0	19.0
2700	2743.2	-	-	25.0	20.0	-	-	25.0	20.0
2800	2844.8	-	-	26.0	21.0	-	-	26.0	21.0
2900	2946.4	-	-	27.0	21.0		-	27.0	21.0
3000	3048.0			29.0	22.0	-	_	29.0	22.0

(12) Steel pipe coated for city water STW (JIS G3443-1987)

(13)	Centrifugal nodular graphite cast iron pipe for city water
	(A type) (JWWA G-105 1971)

Nominal diameter	Р	Actual outer diameter		
		Т		
D	1st type	2nd type	3rd type	D ₁
	pipe	pipe	pipe	
75	7.5	-	6.0	93.0
100	7.5	_	6.0	118.0
150	7.5	169.0		
200	7.5	_	6.0	220.0
250	7.5	-	6.0	271.6
300	7.5	-	6.5	332.8
350	7.5	_	6.5	374.0
400	8.5	7.5	7.0	425.6
450	9.0	8.0	7.5	476.8
500	9.5	8.5	7.0	528.0

(14) Centrifugal nodular graphite cast iron pipe for city water (K type) (JWWA G-105 1971)

Nominal diameter	Р	Actual outer diameter		
D	1st type pipe	2nd type pipe	3rd type pipe	D ₁
400	8.5	7.5	7.0	425.6
450	9.0	8.0	7.5	476.8
500	9.5	8.5	8.0	528.0
600	11.0	10.0	9.0	630.8
700	12.0	11.0	10.0	733.0
800	13.5	12.0	11.0	836.0
900	15.0	13.0	12.0	939.0
1000	16.5	14.5	13.0	1041.0
1100	18.0	15.5	14.0	1144.0
1200	19.5	17.0	15.0	1246.0
1350	21.5	18.5	16.5	1400.0
1500	23.5	20.5	18.0	1554.0

			Nominal thickness			
Nominal	diameter	Outer	Schedule	Schedule	Schedule	Schedule
		diameter	5S	10S	20S	40S
А	В	(mm)	Thickness	Thickness	Thickness	Thickness
~	Ь		mm	mm	mm	mm
150	6	165.2	2.8	3.4	5.0	7.1
200	8	216.3	2.8	4.0	6.5	8.2
250	10	267.4	3.4	4.0	6.5	9.3
300	12	318.5	4.0	4.5	6.5	10.3
350	14	355.6	4.0	5.0	8.0	11.1
400	16	406.4	4.5	5.0	8.0	12.7
450	18	457.2	4.5	5.0	8.0	14.3
500	20	508.0	5.0	5.5	9.5	15.1
550	22	558.8	5.0	5.5	9.5	15.9
600	24	609.6	5.5	6.5	9.5	17.5
650	26	660.4	5.5	8.0	12.7	-
700	28	711.2	5.5	8.0	12.7	-
750	30	762.0	6.5	8.0	12.7	-
800	32	812.8	-	8.0	12.7	-
850	34	863.6	-	8.0	12.7	_
900	36	914.1	-	8.0	12.7	_
1000	40	1016.0	-	9.5	14.3	_

(15) Arc welded large-diameter stainless steel pipe for pipe arrangement (JIS G3468-2004)

(16) Ductile iron specials (JIS G5527-1998)

Nominal diameter	Pipe thickness
(mm)	(mm)
75	8.5
100	8.5
150	9.0
200	11.0
250	12.0
300	12.5
350	13.0
400	14.0
450	14.5
500	15.0
600	16.0
700	17.0
800	18.0
900	19.0
1000	20.0
1100	21.0
1200	22.0
1350	24.0
1500	26.0
1600	27.5
1650	28.0
1800	30.0
2000	32.0
2100	33.0
2200	34.0
2400	36.0

(17) Dimensions of centrifugal sand mold cast iron pipe (JIS G5522)

(010 00022)						
Nominal	Pip	Pipe thickness (T)				
diameter	High	Normal	Low	outer		
D	pressure	pressure	pressure	diameter		
	pipe	pipe	pipe	D ₁		
75	9.0	7.5	_	93.0		
100	9.0	7.5	-	118.0		
125	9.0	7.8	-	143.0		
150	9.5	8.0	7.5	169.0		
200	10.0	8.8	8.0	220.0		
250	10.8	9.5	8.4	271.6		
300	11.4	10.0	9.0	322.8		
350	12.0	10.8	9.4	374.0		
400	12.8	11.5	10.0	425.6		
450	13.4	12.0	10.4	476.8		
500	14.0	12.8	11.0	528.0		
600	-	14.2	11.8	630.8		
700	-	15.5	12.8	733.0		
800	-	16.8	13.8	836.0		
900	-	18.2	14.8	939.0		

(18) Dimensions of centrifugal sand mold cast iron pipe (JIS G5523 1977)

Neurinel	Pipe thic	kness (T)	
Nominal diameter	High	Normal	Actual outer
(mm)	pressure	pressure	diameter D ₁
(((((((((((((((((((((((((((((((((((((((pipe	pipe	
75	9.0	7.5	93.0
100	9.0	7.5	118.0
125	9.0	7.8	143.0
150	9.5	8.0	169.0
200	10.0	8.8	220.0
250	10.8	9.5	271.6
300	11.4	10.0	322.8

(19) Cast iron pipe for waste water(JIS G5525-1975)

Nominal diameter	Pipe thickness	Actual internal diameter	Actual outer diameter
	Т	D ₁	D ₂
50	6.0	50	62
65	6.0	65	77
75	6.0	75	87
100	6.0	100	112
125	6.0	125	137
150	6.0	150	162
200	7.0	200	214

Nominal	Outer	Thickness
diameter	diameter	THICKNESS
13	18	2.5
16	22	
20	26	3.0
25	32	3.5
30	38	3.5
40	48	4.0
50	60	4.5
75	89	5.9
100	114	7.1
150	165	9.6

(21) Arc welded carbon steel pipe STPY (JIS G3457-2005)

()			•••	·	L.		,						(Un	it mass	s: kg/m
Nom diam		Thickness (mm)													
(A)	(B)	Outer diameter (mm)	6.0	6.4	7.1	7.9	8.7	9.5	10.3	11.1	11.9	12.7	13.1	15.1	15.9
350 400	14 16	355.6 406.4	51.7 59.2	55.1 63.1	61.0 69.9	67.7 77.6									
450 500	18 20	457.2 508.0	66.8 74.3	71.1	78.8 87.7	87.5 97.4	107	117							
550	20	558.8	81.8	87.2	96.6	107	118	129	139	150	160	171			
600	24	609.6	89.3	95.2	105	117	129	141	152	164	175	187			
650 700	26 28	660.4 711.2	96.8 104	103	114 123	127 137	140 151	152 164	165 178	178 192	190 205	203 219			
750	30	762.0		119	132	147	162	176	191	206	2203	235			
800	32	812.8		127	141	157	173	188	204	219	235	251	258	297	312
850 900	34 36	863.6 914.4				167 177	183 194	200 212	217 230	233 247	250 265	266 282	275 291	315 335	332 352
1000	40	1016.0				196	216	236	255	275	205	314	324	373	392
1100	44	1117.6						260	281	303	324	346	357	411	432
1200	48 54	1219.2						283	307	331	354	378	390	448	472
1350 1500	54 60	1371.6 1524.0									399 444	426 473	439 488	505 562	532 591
1600	64	1625.6											521	600	631
1800	72	1828.8											587	675	711
2000	80	2032.0												751	791

(22) Stainless steel sanitary pipe (JIS G3447-2004)

Nominal	Outer diameter (mm)	Thickness (mm)	Internal diameter (mm)
1.0S	25.4	1.2	23.0
1.25S	31.8	1.2	29.4
1.5S	38.1	1.2	35.7
2.0S	50.8	1.5	47.8
2.5S	63.5	2.0	59.5
3.0S	76.3	2.0	72.3
3.5S	89.1	2.0	85.1
4.0S	101.6	2.0	97.6
4.5S	114.3	3.0	108.3
5.5S	139.8	3.0	133.8
6.5S	165.2	3.0	159.2

(20) Hard vinyl chloride pipe for city water (JIS K6742-1999)

(23) PVDF-HP

	SDR33 S16 PN10	SDR21 S10 PN16	SDR17 S8 PN20	
Outer diameter (mm)	Thickness (mm)	Thickness (mm)	Thickness (mm)	
16		1.5	1.5	
20		1.9	1.9	
25		1.9	1.9	
32		2.4	2.4	
40		2.4	2.4	
50		3.0	3.0	
63	2.5	3.0		
75	2.5	3.6		
90	2.8	4.3		
110	3.4	5.3		
125	3.9	6.0		
140	4.3	6.7		
160	4.9	7.7		
180	5.5	8.6		
200	6.2	9.6		
225	6.9	10.8		
250	7.7	11.9		
280	8.6	13.4		
315	9.7	15.0		
355	10.8			
400	12.2			
450	13.7			

(24) Heat-resistant hard vinyl chloride pipe PVC-C (JIS G6776-2004)

Nominal diameter	Outer diameter (mm)	Thickness (mm)	Weight (kg/m)
13	18.0	2.5	0.180
16	22.0	3.0	0.265
20	26.0	3.0	0.321
25	32.0	3.5	0.464
30	38.0	3.5	0.561
40	48.0	4.0	0.818
50	60.0	4.5	1.161

Polyethylene pipe for city water service (Japan Polyethylene Pipes Association for Water Service standard PTC K 03:2006)

Nominal diameter	Outer diameter (mm)	Thickness (mm)	Inner diameter (mm)	Weight (kg/m)
50	63.0	5.8	50.7	1.074
75	90.0	8.2	72.6	2.174
100	125.0	11.4	100.8	4.196
150	180.0	16.4	145.3	8.671
200	250.0	22.7	201.9	16.688

T°C	Vm/s	T°C	Vm/s	T°C	Vm/s	T°C	Vm/s
0	1402.74						
1	1407.71	26	1499.64	51	1543.93	76	1555.40
2	1412.57	27	1502.20	52	1544.95	77	1555.31
3	1417.32	28	1504.68	53	1545.92	78	1555.18
4	1421.96	29	1507.10	54	1546.83	79	1555.02
5	1426.50	30	1509.44	55	1547.70	80	1554.81
6	1430.92	31	1511.71	56	1548.51	81	1554.57
7	1435.24	32	1513.91	57	1549.28	82	1554.30
8	1439.46	33	1516.05	58	1550.00	83	1553.98
9	1443.58	34	1518.12	59	1550.68	84	1553.63
10	1447.59	35	1520.12	60	1551.30	85	1553.25
11	1451.51	36	1522.06	61	1551.88	86	1552.82
12	1455.34	37	1523.93	62	1552.42	87	1552.37
13	1459.07	38	1525.74	63	1552.91	88	1551.88
14	1462.70	39	1527.49	64	1553.35	89	1551.35
15	1466.25	40	1529.18	65	1553.76	90	1550.79
16	1469.70	41	1530.80	66	1554.11	91	1550.20
17	1473.07	42	1532.37	67	1554.43	92	1549.58
18	1476.35	43	1533.88	68	1554.70	93	1548.92
19	1479.55	44	1535.33	69	1554.93	94	1548.23
20	1482.66	45	1536.72	70	1555.12	95	1547.50
21	1485.69	46	1538.06	71	1555.27	96	1546.75
22	1488.63	47	1539.34	72	1555.37	97	1545.96
23	1491.50	48	1540.57	73	1555.44	98	1545.14
24	1494.29	49	1541.74	74	1555.47	99	1544.29
25	1497.00	50	1542.87	75	1555.45	100	1543.41

(26) Velocity of sound subject to change temperature in water (0 to 100°C)

Note) T: temperature, V: velocity of sound

(28) Velocity of sound per piping material

(27) Velocity of sound and density of various liquids

·			
Name of liquid	T°C	ρg/cm³	Vm/s
Acetone	20	0.7905	1190
Aniline	20	1.0216	1659
Alcohol	20	0.7893	1168
Ether	20	0.7135	1006
Ethylene glycol	20	1.1131	1666
n-octane	20	0.7021	1192
o-xylene	20	0.871	1360
Chloroform	20	1.4870	1001
Chlorobenzene	20	1.1042	1289
Glycerin	20	1.2613	1923
Acetic acid	20	1.0495	1159
Methyl acetate	20	0.928	1181
Ethyl acetate	20	0.900	1164
Cyclohexane	20	0.779	1284
Dithionic acid	20	1.033	1389
Heavy water	20	1.1053	1388
Carbon tetrachloride	20	1.5942	938
Mercury	20	13.5955	1451
Nitrobenzene	20	1.207	1473
Carbon disulfide	20	1.2634	1158
Chloroform	20	2.8904	931
n-propyl alcohol	20	0.8045	1225
n-pentane	20	0.6260	1032
n-hexane	20	0.654	1083
Light oil	25	0.81	1324
Transformer oil	32.5	0.859	1425
Spindle oil	32	0.905	1342
Petroleum	34	0.825	1295
Gasoline	34	0.803	1250
Water	13.5	1.	1460
Sea water (salinity: 3.5%)	16	1.	1510

Note) T: temperature, ρ : density, V: velocity of sound


(29) Dynamic viscosity coefficient of various liquids


Material	Vm/s
Iron	3230
Steel	3206
Ductile cast iron	3000
Cast iron	2460
Stainless steel	3206
Copper	2260
Lead	2170
Aluminum	3080
Brass	2050
Vinylchloride	2640
Acrylics	2644
FRP	2505
Mortar	2500
Tar epoxy	2505
Polyethylene	1900
TFE	1240

Note) V: velocity of sound

Name of liquid	T°C	ρg/cm³	Vm/s	v (×10⁻6m²/s)
Acetone	20	0.7905	1190	0.407
Aniline	20	1.0216	1659	1.762
Ether	20	0.7135	1006	0.336
Ethylene glycol	20	1.1131	1666	21.112
Chloroform	20	1.4870	1001	0.383
Glycerin	20	1.2613	1923	1188.5
Acetic acid	20	1.0495	1159	1.162
Methyl acetate	20	0.928	1181	0.411
Ethyl acetate	20	0.900	1164	0.499
Heavy water	20	1.1053	1388	1.129
Carbon tetrachloride	20	1.5942	938	0.608
Mercury	20	13.5955	1451	0.114
Nitrobenzene	20	1.207	1473	1.665
Carbon disulfide	20	1.2634	1158	0.290
n-pentane	20	0.6260	1032	0.366
n-hexane	20	0.654	1083	0.489
Spindle oil	32	0.905	1324	15.7
Gasoline	34	0.803	1250	0.4 to 0.5
Water	13.5	1.	1460	1.004(20°C)

Note) T: temperature, ρ : density, V: velocity of sound v: kinematic viscosity





16.3 Specifications

Measuring objects

Measurement fluid: Turbidity of fluid: State of fluid: Fluid temperature: Measuring range:	Uniform liquid in which ultrasonic waves can propagate. 10000 mg/L or less Well-developed turbulent or laminar flow in a filled pipe. -40 to +200°C 0···±0.3 to ±32m/s
Piping conditions	
Applicable piping material:	Select from carbon steel, stainless steel, cast iron, PVC, FRP, copper, aluminum, acrylic or material of known sound velocity.
Pipe size:	Flow rate measurement φ13 to φ6000mm Flow velocity profile measurement φ40 to φ1000mm
Lining material:	Select from no lining, tar epoxy, mortar, rubber, Teflon, pyrex glass or material of known sound velocity. Note) No gap allowed between the lining and the pipe.
Straight pipe length:	10D or more upstream and 5D or more downstream (D: internal pipe diameter) Refer to Japan Electric Measuring Instruments Manufactures' Association's standard

Performance specifications

Accuracy rating:				
Piping diameter (inner diameter)	Flow velocity range	Accuracy		
12 to 125mm	2 to 32m/s	±2.5% of rate		
φ13 to φ25mm	0 to 2m/s	±0.05m/s		
φ25 to φ50mm	2 to 32m/s	±1.5% of rate		
φ25 το φ501111	0 to 2m/s	±0.03m/s		
φ50 to φ300mm	2 to 32m/s	±1.0% of rate		
φ30 to φ300mm	0 to 2m/s	±0.02m/s		
+200 to +6000mm	1 to 32m/s	±1.0% of rate		
φ300 to φ6000mm	0 to 1m/s	±0.01m/s		

JEMIS-032 for details.

Note) Reference conditions are based on JEMIS-032.

Flow transmitter Type: PUX2

Power supply:	Built-in battery or AC power adapter
Built-in battery:	Exclusive lithium button battery (5000m Ah)
	Continuous operation time, approx. 12 hours (without printer, back light OFF, Not use the current output, the ambient temperature is near normal temperature (20°C).)
	The charging time range: 0 to +40°C
	Recharging time, approx. 3 hours (power adapter used)
Power adapter:	Exclusive power adapter 90V to 264V AC (50/60Hz)
Power Consumption:	Approx. 3W
LCD:	Semi-transmissive color graphic display 240 × 320 (with back light)
	Measurement value (instantaneous flow rate, integrated flow rate) and various settings are displayed.
	Excellent visibility even outdoors in direct sunlight.
LED display:	Status display when using AC power adapter.
	DC IN (green): Power supply status
	CHARGE (red): Battery charging underway
Operation keypad:	11 buttons (ON, OFF, ENT, ESC, MENU, \triangle , \bigtriangledown , \triangleleft , \triangleright , LIGHT, PRINT)
Power failure backup:	Measurement value is backed up by nonvolatile memory.
	Clock backup with lithium battery (effective term, 10 years or more)
Response time:	1 second


Analog output signals:	4 to 20mA DC, one point (load resistance, 600Ω or less)
	Instantaneous velocity, instantaneous flow rate or heat quantity (calorie) after scaling.
Analog input signal:	4 to 20mA DC, one point (input resistance, 200 Ω or less) Total
	4 to 20mA DC, one point (input resistance, 200 Ω or less) 2 points
	or 1 to 5V DC, one point
	Used to input temperature for heat quantity measurement, etc.
SD memory card:	Used for data logger function and recording screen data.
	Available up to 8GB (Option256MB)
	Compliant media
	• SD memory card: speed class 2, 4, 6
	SDHC memory card: speed class 4, 6
	Format
	• FAT12: 64MB
	• FAT16: 128MB to 2GB
	• FAT32: 4GB, 8GB
	Otherwise, reading and saving are impossible.
	File format
	Date logger: CSV file
Serial communication:	Screen date: Bit map file USB port (device* compatible):
Senar communication.	Mini B receptacle
	Connectable number of Mini B receptacles:
	1 unit
	Transmission distance: 3m max.
	Transmission speed: 500kbps
	Data:
	Instantaneous velocity, instantaneous flow rate, total value, heat quantity (calorie)
	value, error information, logger data, etc.
	* Device: Connected plug from PC
Printer (option):	To be mounted on top of transmitter unit
	Thermal line dot printing
	For selecting Chinese, the printing character will be Japanese Kanji character.
Ambient temperature:	-10 to +55°C (Without printer)
	−10 to +45°C (With printer)
Ambient humidity:	90%RH or less
Type of enclosure:	IP64 (Without printer)
Enclosure case:	Plastic case
Outer dimensions:	H210 × W120 × D65mm (Without printer)
	H320 × W120 × D65mm (With printer)
Weight:	1.0kg (Without printer)
	1.2kg (With printer)
Various functions	
Display language:	Selectable from Japanese, English, German, French, Spanish or Chinese (switchable by
Display language.	key operation).
Clock display function:	Time (year, month, day, hour, minute) display (configurable)
	Monthly error: about 1 minute at common temperature (20°C). However, time error at
	power ON/OFF is not included.
Instantaneous value displa	
•	Instantaneous velocity, instantaneous flow rate display (The flow in reverse direction is

Diapley Janguages	Colortable from Janapases English Corresp Erench Spanish or Chineses (switchable by
Display language:	Selectable from Japanese, English, German, French, Spanish or Chinese (switchable by key operation).
Clock display function:	Time (year, month, day, hour, minute) display (configurable)
	Monthly error: about 1 minute at common temperature (20°C). However, time error at
	power ON/OFF is not included.
Instantaneous value displ	ay function:
	Instantaneous velocity, instantaneous flow rate display (The flow in reverse direction is displayed with minus "")
	Numeric value: 10 digits (decimal point equals 1 digit)
	Unit: Metric/English system selectable
	Metric system
	Velocity: m/s
	Flow rate: L/s, L/min, L/h, L/d, kL/d, ML/d, m³/s, m³/min, m³/h, m³/d, km³/d, Mm³/d, BBL/s, BBL/min, BBL/h, BBL/d, kBBL/d, MBBL/d
	English system
	Velocity: ft/s
	Flow rate: gal/s, gal/min, gal/h, gal/d, kgal/d, Mgal/d, ft³/s, ft³/min, ft³/h, ft³/d, kft³/d, Mft³/d, BBL/s, BBL/min, BBL/h, BBL/d, kBBL/d, MBBL/d

Bulletin F-9-PUX2

Total value display function: Display of forward or reverse total (reverse is displayed as minus) Numeric value: 10 digits (decimal point is corresponding to 1 digit) Unit: Metric/English system selectable Metric system Flow rate total: mL, L, m³, km³, Mm³, mBBL, BBL, kBBL English system Flow rate total: gal, kgal, ft³, kft³, Mft³, mBBL, BBL, kBBL, ACRE-ft Consumed heat quantity (calorie) display function: Display of consumed heating medium Metric system Heat flow: MJ/h, GJ/h Total heat quantity: MJ, GJ English system Heat flow: MJ/h, GJ/h, BTU/h, kBTU/h, MBTU/h Total heat quantity: MJ, GJ, BTU, kBTU, MBTU Computation function of consumed heat quantity (calorie):

This function calculates the heat quantity received and sent with liquid (water) in cooling and heating.



T2: Fluid temperature (out) Q: Flow rate of the fluid

Temperature display function:

Metric system Temperature unit: °C or K English system Temperature unit: F or K Site data storage function: Max. 32 locations (sites) data (pipe size, material, fluid type and etc) can be stored into built-in non-volatile memory. Damping: 0 to 100sec (every 0.1sec) configurable for analog output and velocity/flow rate display
English system Temperature unit: F or K Site data storage function: Max. 32 locations (sites) data (pipe size, material, fluid type and etc) can be stored into built-in non-volatile memory.
Site data storage function: Max. 32 locations (sites) data (pipe size, material, fluid type and etc) can be stored into built-in non-volatile memory.
built-in non-volatile memory.
Damping: 0 to 100sec (every 0.1sec) configurable for analog output and velocity/flow rate display
Low flow cut: Equivalent to 0 to 5m/s
Output setting function: Current output scaling, output type, burnout setting and calibration
Serial communication function:
Instantaneous velocity, instantaneous flow rate, total value, heat flow, error information, received waveform, analog input, velocity profile data, logger data, etc. may be down- loaded to personal computer.
Logger function: Instantaneous velocity, instantaneous flow rate, total value, heat flow, error information, received waveform, analog input, velocity profile date can be saved in a SD memory card.
Waveform display function: Bi-directional received waveforms may be displayed.
Graph display function: Flow rate trend graph may be displayed.
Printing function (option): Hard copy output of a screen
Periodic printing (type: text, graph)
Logger date (type: text, graph)
Flow velocity profile measurement (option):
Flow velocity profile may be observed in real time using the exclusive detector (option).

Detector Type: PSX2

Type of detector:

31				
Kind	Туре	Internal pipe diameter (mm)	Fluid temperature	
Small type	PSX2-A	φ50 to φ400	-40 to 100°C	
Small diameter	PSX2-B	φ13 to φ100	-40 to 100°C	
High temperature	PSX2-HT	φ50 to φ400	-40 to 200°C	
Middle type	PSX2-C	φ200 to φ1200	-40 to 80°C	
Large type	PSX2-D	φ200 to φ6000	-40 to 80°C	
Sensor mounting method: Signal cable: Method for connection: Ambient temperature: Ambient humidity: Type of enclosure:		Standard 5m Flow transmitter side Exclusive connector Detector side Large/middle type: Scre Others: BNC connector -20 to +60°C	Flow transmitter side Exclusive connector Detector side Large/middle type: Screw terminal Others: BNC connector -20 to +60°C Large/middle type sensor: 100%RH or less Others: 90%RH or less	
Type of enclosure:		Large/middle type sensor: Others: IP52	0 11	

Material and mounting belt/wire:

Kind	Туре	Sensor case	Mounting bracket	Mounting belt /wire
Small diameter	PSX2-B	Plastic	Aluminum alloy + Plastic	Plastic cloth belt
Small type	PSX2-A	Plastic	Aluminum alloy + Plastic	Plastic cloth belt
Middle type	PSX2-C	Plastic		Stainless wire
Large type	PSX2-D	Plastic		Stainless wire
High temperature	PSX2-HT	SUS304	Aluminum alloy + SUS304	Stainless belt

Extension cable (option):

Extended when the length of the detector signal cable is not sufficient. Length: 10m, 50m

Reserved for future use

16.4 Q&A

I. Q & A about pipes

1. How is piping setting made when piping specifications are unknown?

- Flow rate can be measured within the range of the specifications of transmitter by entering the standard value, but the accuracy cannot be guaranteed.
 - * Outer diameter can be confirmed by measuring the outside circumference.
 - * Thickness can be confirmed by using a piping thickness gauge available optionally.

2. What is the effect of coating outside the piping ?

In general, when the outside wall of the piping is rusted and contaminated with deposits of foreign objects, coating materials, etc., so the sensor is not fitted firmly to the piping, measurement cannot be made if there is an air gap which prevents the passage of ultrasonic waves. In this case, the sensor should be mounted after removing the contamination.

Measurement at a point with uniform coating can be made without problems.

There are no problems with a thick coating (more than several mm), but the measurement accuracy can be improved by adding the lining thickness to the coating thickness and entering it prior to measurement.

When wrapped with jute, the jute should be removed before measurement.

3. What is the effect of scales in the piping ?

Measurement can be made even when there are scales in the piping, but the amount of reduction of the sectional area due to scaling will become an error.

Therefore, the flow indicated is a little larger than the actual flow.

When the scale thickness is known, it can be compensated by adding it to the lining thickness and entering it for measurement. In general, the state of deposit of scales in old piping is not uniform, and shows an uneven surface. Therefore, an accurate cross-sectional area of flow passage cannot be measured.

Also, the flow profile is not uniform, and an accurate measurement of flow cannot be expected, strictly speaking.

II. Q & A about fluids

1. What is homogeneous fluid through which ultrasonic waves are transmitted ?

Municipal water can be measured over the range from raw water to clean water without problems. Sewage flows can be measured up to return sludge.


If the flow contains many air bubbles, it cannot be measured. In general, the less foreign objects (including air bubbles) the flow contains, the more easily can it be measured.

2. Is it possible to measure the flow in piping that is not full?

In horizontal piping, if the pipe is filled with liquid up to 2/3 of inside diameter D as shown below, the flow velocity can be measured. In this case, the flow rate indicated is the assumed one under filled pipe conditions.


Therefore, the flow indicated is larger than the actual flow.

If sludge is accumulated on the bottom of the piping, the flow velocity can be measured up to 1/3 of inside diameter D. In this case, the flow rate indicated is the assumed one under filled pipe conditions without any sludge.



3. What happens when the liquid contains air bubbles ?


The transmitter is highly resistant to entry of air bubbles in pipes with the aid of the advanced ABM system as shown below.



* Example of measured data

When liquid contains excessive air bubbles, no measurement can be made because of transmission failure of the ultrasonic waves. When air bubbles enter the liquid momentarily, the output is retained by the self-check function, thereby causing no problems. Air bubbles easily enter liquid in the following cases.


- (1) Suction of air due to low liquid level of pump well
- (2) Occurrence of cavitation
- (3) Pressure in the piping becomes negative and air enters from piping connection.



III Q & A about measuring conditions at locations

1. What about mounting the sensor on horizontal piping?

The sensor should be mounted in the horizontal direction on the piping circumference to prevent the effects of accumulated sludge (lower) and air bubbles (upper).



2. What about mounting the sensor on vertical piping ?

The sensor can be mounted on any external position of vertical piping. The recommendable flow direction is upward to avoid the interference of bubbles.

3. When the length of straight piping is short and a pump, valve, orifice, etc. is present, what is required for measurement ? In general, the length of straight piping on upstream side should be longer than 10D, and that

on downstream side should be longer than 5D. When a pump, valve, orifice, etc. is present, measurement should be made at a location greater than 30D away on the upstream side and greater than 5D away on the downstream side.

4. How far can the sensor extension cord be extended ?

Extension cords can be connected and extended up to 100m. (Special cable with BNC connector: $10m \times 2$ or $50m \times 2$ available optionally)

IV. Q & A about accuracy

1. What is the approximate accuracy of measurement ? Specifications:

Inside diameter	Flow velocity	Accuracy
φ15 to φ25 or less	2 to 32m/s	± 2.5% of measured flow
	0 to 2m/s	± 0.05m/s
φ25 to φ50 or less	2 to 32m/s	± 1.5% of measured flow
	0 to 2m/s	± 0.03m/s* ¹
φ50 to φ300 or less	2 to 32m/s	± 1.0% of measured flow
	0 to 2m/s	± 0.02m/s
φ300 to φ6000	1 to 32m/s	± 1.0% of measured flow
	0 to 1m/s	± 0.01m/s

*1: Example of calculation

Error at 2m/s? $\rightarrow \pm 0.03 \times 100/2 = \pm 1.5\%$ Error at 1m/s? $\rightarrow \pm 0.03 \times 100/1 = \pm 3.0\%$

Formerly, the expression \blacksquare % of full scale was often used. But, in the recent age of digital system, it is more frequently expressed in % of the displayed value. Under the condition of low flow velocity, the absolute value of error is used as a standard of accuracy in consideration of the threshold of device performance.


2. What about error factors ?

On the transmitter, ultrasonic waves are emitted from the outside of the piping and the time is measured while the waves are passing through the piping material - fluid - piping material. The following points become the error factors to be considered when evaluating the measured values.

(1) Piping size


When the value set for piping size is different from the actual size of piping, and if the difference from the inside diameter is about 1% in size, the error is about 3% of deviation obtained by flow conversion.

(The following shows an example of 1mm deviation in inside diameter)



(2) Difference in sensor mounting length

As a general standard, when the error in mounting length is ± 1 mm, the error of flow is within 1%.




(3) Flow in piping is deviated

When the straight piping is short (particularly upstream side), the flow has become skewed and some deviation error will occur, or fluctuation of indicated value will occur when the flow is swirling.

(4) Inside diameter different from set value due to deposits of scales inside the piping The error is the same as noted in (1). If scales are badly deposited, receiving waves are not available and measurement may be disabled.

(5) Change in water temperature

Sound velocity of the water is calculated in real time and change in fluid temperature is compensated (new sound velocity measuring system), but there is a slight error.



* Example of measurement

(6) Weak received wave due to improper mounting condition and piping condition

Measurement may be possible. But, if received wave is weak, it may result in a large error due to the effect of external noise.

(7) Output when the liquid contains air bubbles

When the amount of air bubbles contained in the liquid is lower than the allowable value indicated before, the unit indicates volume flow containing air bubbles.

3. What about comparison with other flowmeters ?

Although thermometers and pressure gauges can easily be calibrated at a site, flowmeters are generally very difficult to calibrate at a site.

Therefore, the flowmeter transmitter unit is often used for checking other flowmeters. After checking, the result of comparison of flowmeters should be evaluated with care while considering to the following points.

(1) Consideration of error of each flowmeter

Evaluate the calibration error in consideration for accuracy indication (percentage in FS or percentage of the rate)

(2) Study data systematically, if an error is found.

Do not compare values only at 1 point of flow. Draw many samples on a graph and arrange them systematically for clear evaluation.

(3) Thoroughly check the piping system.

If fluid flows into or out of a branch pipe in the middle of a piping system, the comparison data of each side of such a pipe-junction may not match each other.

When there is storage in the middle of piping system and it becomes a buffer for the flow, the liquid level of the storage area should be taken into consideration.

(4) Comparison of 2 different sets of flowmeters is difficult.

When there is a difference between 2 sets of flowmeters, it is difficult to judge the correct one. So, another judgement criteria needs to be considered.

V. Others

1. Life span of LCD

The life span of LCD is considered to be about 10 years under general operating conditions, according to the manufacturer's catalogue. Generally, it is about 5 to 6 years in actual service. The life span is not so much related to the number of displaying operations.

2. Printer roll sheet

(1) Supplied printer roll sheet is 28 meters long.

The roll sheet is fed at 0.125 mm/dot. Setting the paper feed at a cycle of 1 second uses a roll of paper in 224,000 sec. (about 62.2 hours) = 28 m /0.125 mm.

(2) In case of TEXT mode

A single printing consists of the following:

- 1) Date (1 line),
- 2) Flow velocity, flow rate, and total (several lines),
- 3) Measuring conditions (1 line)
- 4) Paper-feed (4 mm)

A printer has a paper fed at 4 mm/line.

For example, if you select flow rate (m^3/h) , flow velocity and +total, the paper feed totals 5 lines (24 mm). If a printing cycle is assumed to set to 1 minute, a roll of paper will be used for 1167 minutes (about 19.4 hours) = 28 meters/24 mm

16.5 File contents of SD memory card

16.5.1 Types of measured data to be logged

Measured data to be logged is of 14 types indicated below.

Table 16-1 Data types					
Kind	Name	Sign	Maximum number of places of integer section	Number of places of decimal	Unit
VELOCITY	VELOCITY	Yes	3 places	3 places	m/s
FLOW RATE	FLOW RATE	Yes	12 places	4 places	Flow unit
FLOW RATE (%)	FLOW RATE (%)	Yes	3 places	3 places	%
+TOTALIZER	+TOTAL (ACTUAL)	No	10 places	3 places	Total unit
-TOTALIZER	-TOTAL (ACTUAL)	No	10 places	3 places	Total unit
AI CHANNEL 1	Analog input channel 1	Yes	10 places	3 places	_
AI CHANNEL 2	Analog input channel 2	Yes	10 places	3 places	_
FEEDING TEMP.	SENDING TEMPERATURE	Yes	3 places	3 places	Temperature unit
RETURNING TEMP.	RETURN TEMPERATURE	Yes	3 places	3 places	Temperature unit
DIFFERENCE TEMP.	DIFFERENCE OF TEMPERATURE	Yes	3 places	3 places	Temperature unit
THERMAL FLOW	HEAT FLUX	Yes	10 places	3 places	Thermal flow unit
THERMAL FLOW (%)	HEAT FLUX (%)	Yes	3 places	3 places	%
+TOTAL (THERMAL)	+HEAT TOTAL (ACTUAL)	No	10 places	3 places	Total unit (Thermal)
-TOTAL (THERMAL)	-HEAT TOTAL (ACTUAL)	No	10 places	3 places	Total unit (Thermal)

In case heat mode is "NOT USED", it is invalid even if feeding temperature and subsequent have been selected.

If the system unit was changed after logger start, logging is performed in the unit at the time of start. The changed unit becomes valid after the logger is stopped.

16.5.2 Measured data file

(1) Configuration data file

A file is roughly configured of three sections.

• Section [START] A file is generated at start, and this section is created at that time.

Item	Contents	
PRODUCT	Product name, fixed	
VERSION	File format version number (1.0.0, fixed)	
TIME	Logger start date and hour	
CYCLE	Logger acquisition period (sec)	

• Section [DATAx] Added at the time of generation of target data file.

Item	Contents			
FILE	File name of log	File name of logger data		
INDEXx		(date and hour) data in the logger data is added sequentially		
		as indicated below.		
	1	nber of data in offset, date/hour of offset)		
TIME	Logger data exit	date and hour		
COUNT	Total number of data in target data file			
STATUS	Exit status			
	NORMAL:	Normal exit caused by termination of acquisition period		
	STOP:	Normal exit caused by stop operation during acquisition		
	POWER OFF:	Interruption caused by OFF button during acquisition		
	BATTERY LOW: Interruption caused by battery capacity drop during acquisi-			
		tion		
	FIFO EMPTY:	No vacancy in measurement FIFO		
	ABNORMAL:	Stop caused by system error during acquisition		
SIZE	Byte size of target data file			
SUM	Total number of data up to target data file			

• Section [END] Added at the time of termination of the logger.

Item	Contents			
PRODUCT	Logger exit date and hour			
VERSION	Total byte size of all data files			
TIME	Number of all data files			
CYCLE	Total number of data			

[START]	
PRODUCT=	
VERSION=V1.0.0	
TIME=2007/01/01 00:00:00	
CYCLE=00:00:01	
[DATA1]	
FILE=AAA_20071214_193032.csv	
INDEX1=490047,5000,2007/12/14 20:53:51	
INDEX2=980047,10000,2007/12/14 22:17:11	
INDEX3=1470047,15000,2007/12/14 23:40:31	
INDEX4=1960047,20000,2007/12/15 01:03:51	
INDEX5=2450047,25000,2007/12/15 02:27:11	
INDEX6=2940047,30000,2007/12/15 03:50:31	
INDEX7=3430047,35000,2007/12/15 05:13:51	
INDEX8=3920047,40000,2007/12/15 06:37:11	
INDEX9=4410047,45000,2007/12/15 08:00:31	
INDEX10=4900047,50000,2007/12/15 09:23:51	
INDEX11=5390047,55000,2007/12/15 10:47:11	
INDEX12=5880047,60000,2007/12/15 12:10:31	
INDEX13=6370047,65000,2007/12/15 13:33:51	
TIME=2007/12/15 13:42:11	
COUNT=65500	
STATUS=NORMAL	
SIZE=6419145	
SUM=65500	
[END]	
TIME=2007/12/17 09:52:11	
SIZE=6419145	
FCOUNT=1	
SUM=65500	

(2) Data file

A file is generated in CSV format.


The following table shows the contents displayed when data is accessed via spreadsheet software.

Line	Row	Contents
1	A	
Line 1	B and subsequent	Names of logged types for the quantity, including RAS. ASCII characters show names. See "16.5.1 Types of measured data to be logged".
Line 2	B and subsequent	Units of logged types for the quantity. ASCII characters show units.
Line 3 and subsequent	A	Date and hour
Line 3 and subsequent	B and subsequent	Date/hour name measured data and RAS. 32-bit binary numbers indicates RAS. See "16.5.4 Regarding RAS".

Table 16-2	Contents	of data file
------------	----------	--------------

	А	В	С	D	E
1	4	VELOCITY	FLOW RATE	TOTAL FORWARD	RAS
2		m/s	m3/s	L	
3	2009/9/30 11:00:00	1.23	123.45	1234.56	1 001 000
4	2009/9/30 11:10:00	1.24	123.46	1234.57	1 001 000
5	2009/9/30 11:20:00	1.25	123.47	1234.58	1 001 000
6	2009/9/30 11:30:00	1.26	123.48	1234.59	1 001 000
7	2009/9/30 11:40:00	1.27	123.49	1234.6	1 001 000
8	2009/9/30 11:50:00	1.28	123.5	1234.61	1 001 000
9	2009/9/30 12:00:00	1.29	1 2 3.51	1234.62	1 001 000
10	2009/9/30 12:10:00	1.3	123.52	1234.63	1 001 000
11	2009/9/30 12:20:00	1.31	123.53	1234.64	1 001 000
12	2009/9/30 12:30:00	1.32	123.54	1234.65	1 001 000
13	2009/9/30 12:40:00	1.33	123.55	1234.66	1 001 000
14	2009/9/30 12:50:00	1.34	123.56	1234.67	1 001 000
15	2009/9/30 13:00:00	1.35	123.57	1234.68	1 001 000
16	2009/9/30 13:10:00	1.36	123.58	1234.69	1 001 000

When data is indicated in a point diagram spreadsheet chart, it may appear as indicated below.



16.5.3 Flow velocity profile data file

A file is generated in the CSV format indicated below, and it contains data for up to one hour. The following table shows the contents displayed when data is accessed via spreadsheet software.


Line	Row	Contents		
Line 2	A	Describes " <measurement result="">".</measurement>		
	B and subsequent	Describes "Channel number".		
	C and subsequent	Channel number		
		126 to 1, 1 to 126 in case of connection of sensor U 1 to 126, 126 to 1 in case of connection of sensor D 1 to 126, 126 to 1 to 17 multiple case of connection of sensor U/D		
	IU	1 to 126, 126 to 1 to IT row in case of connection of sensor U/D Describes " <f.rate vel.value="">".</f.rate>		
	IV	Describes " <ras>".</ras>		
Line 3	В	Describes " <start channel="" end="">".</start>		
	C and subsequent	Describes 1 in start/end channels of channel number in line 2, and describes 0 in others.		
Line 4	А	Describes " <measurement time="">".</measurement>		
Line 4	С	Describes acquisition date/hour in the "2007/10/29 10:19:44" format.		
	A	Describes " <velocity data="" measurement="" profile="" the="">".</velocity>		
Line 5 and subsequent	C to IU	Fluid velocity that corresponds to channel number in line 2.		
	IU	Flow rate/fluid velocity at acquisition date/hour.		
	IV	RAS is indicated by 32-bit binary numbers, with " " added at first. See "16.5.4 Regarding RAS ".		

Table 16-3	Contents	of flow	velocity	distribution file
------------	----------	---------	----------	-------------------

A flow velocity distribution file can be displayed using flow velocity distribution demonstrate function of PC loader software.

16.5.4 Regarding RAS

Expresses the status of the measurement screen by 32-bit binary numbers.



Dwyer Instruments, Inc.

Corporate Headquarters 102 Indiana Highway 212 P.O. Box 373 Michigan City, IN 46361 U.S.A.

Telephone: 219/879-8000 Fax: 219/872-9057

www.dwyer-inst.com

BULLETIN F-9-PUX2 TN1FSCA-E-D